



**Saeco Minuto
Super-automatic
espresso machine**

- Brews 7 coffee varieties
- Automatic Milk Frother
- Black
- 5 step adjustable grinder



HD8762/03

Always your favorite coffee at just one touch

With the one-click removable brewing group

Only the Saeco Minuto super-automatic espresso machine delivers the real first bean to cup experience with maximum convenience, top-notch performance and large capacities in extra compact dimensions

Authentic Italian coffee perfection

- Coffee without burnt taste thanks to 100% ceramic grinders
- Coffee without waiting thanks to the quick heat boiler

Authentic Italian coffee perfection

- Delicious froth thanks to a patented automatic milk frother

Ease of cleaning and maintaining

- Easy cleaning thanks to removable brewing group

Ease of cleaning and maintaining

- Dishwasher-safe drip tray and servings container
- Fully automatic rinsing and de-scaling

Set the beverages to suit your taste

- Save your favorite coffee settings
- Avoid heat loss and fit every cup with our adjustable spout
- Play with the coffee's richness with our adjustable grinders

 **Saeco**



Highlights

100% ceramic grinders



This espresso machine is equipped 100% ceramic grinders. Saeco uses ceramic grinders because of their consistent grind without overheating the coffee bean for an impeccable espresso. Ceramic also ensures long-lasting performance and a totally silent operation.

Quick heat boiler



The Saeco quick heat boiler technology ensures your machine is always ready. Now you won't have to wait between brewing each espresso, but can prepare coffee after coffee.

Automatic milk frother



Preparing a tasty cappuccino is easy with this Saeco espresso machine thanks to the new,

patented automatic milk frother with its cyclonic chamber. The milk frother, which baristas also call "cappuccinatore", will draw milk directly from a milk carton or jug and froth it automatically, dispensing it directly into your cup. And thanks to the exclusive cyclonic chamber, a constant flow of milk without any splashing is guaranteed.

Saves your coffee settings



You will always get a perfect cup of espresso brewed just for you, according to your personal preference, thanks to our innovative memo function to adjust the coffee length, strength and temperature. Enjoy a superb coffee drink in your favorite cup with just the press of a button.

Adjustable spout



The adjustable spout on our espresso machines will fit every cup and thus prevents the coffee splashing or cooling down while pouring in your cup. This way your espresso is always served at the right temperature while maintaining a clean machine.

Dishwasher-safe drip tray-part

You can comfortably put the drip tray and servings container in your dishwasher, giving them a perfect time-saving clean.

5 step adjustable grinders



Different coffee blends require different levels of granularity for the full flavor to unfold. The grind granularity of this espresso machine can be adjusted in 5 settings, from the finest grind, for a full bodied espresso, to the coarsest, for a lighter coffee.

Removable brewing group



The brewing group, a Saeco invention, is the heart of our espresso machines, ensuring automation. The brewing group is, depending on the model, easily accessible from the front or side. It can be removed effortlessly for easily cleaning by rinsing under the tap ensuring maximum hygiene.

Fully automatic rinsing

Easy maintenance, long-lasting performance and always the best result in the cup are ensured thanks to our fully automated rinsing and de-scaling program.

Specifications

Easy to use

- Cleaning and maintenance: Descaling cycle
- Usage: Adjustable coffee dispenser, Rapid steam, Removable brewing group, Normal / long espresso option

Weight and dimensions

- Product dimensions (L x D x H): 215 x 429 x 330 mm
- Coffee bean capacity: 250 g
- Product weight: 7.5 kg
- Waste container capacity: 15 servings
- Maximum cup height: 152 mm
- Water tank capacity: 1.8 L

Technical specifications

- Supported coffee types: Ground coffee, Whole coffee beans
- Cord length: 80 cm
- Power: 1850 W
- Voltage: 240 V

- Frequency: 50 Hz
- Country of origin: Made in Europe, Designed in Italy
- Water pressure in pump: 15 bar (perfect espresso)
- Number of water boilers: 1 boiler
- Removable brewing group

Features

- Brita Filter compatible: Optionable
- Simultaneous brewing

Perfect Espresso

- Espresso technology: Saeco adapting system, Aroma-system: pre-brewing

Design

- Colour: Mat Black
- Materials and finishing: Plastic

Service

- 2-year worldwide guarantee