



SENSEO®
Coffee pod machine

• Supreme

HD7832/55

Simply good drip filter coffee

Deluxe and Supreme coffee machines

Having your coffee exactly the way you like it just got easier thanks to the range of SENSEO® Deluxe and Supreme coffee machines. These are the simplest and most convenient appliances that you can adjust to make your Coffee your way.

Sensational coffee

- Delicious coffee foam layer for your special coffee moment

Design

- Metallic accents for premium look

Sensational coffee

- Large coffee pod variety to accommodate choice
- Volume Select option to customize and optimize coffee volume

Ultimate convenience

- Automatic shut-off for less energy consumption
- 1 or 2 cups of SENSEO® coffee in less than a minute
- Removable extra-large water reservoir for fewer refills
- Water-level feedback lights for more convenience
- LCD display for better control and easy use
- Adjustable spout to fit your favorite cup



* Based on retail sales volumes

Senseo®

PHILIPS

Highlights

Large coffee pod variety



With more than 250 years of experience, Douwe Egberts knows exactly how to roast and grind carefully selected coffee beans for the best taste. Therefore Douwe Egberts SENSEO® coffee pod varieties represent the finest coffee selection as a guarantee for premium taste. The different blends and flavors ensure a wide range of choice for different moments and tastes.

Delicious coffee foam layer



The fine Douwe Egberts SENSEO® coffee selection and the unique SENSEO® brewing system make sure that your perfect cup of coffee always comes with a rich and delicious coffee foam layer - proof of premium taste and quality.

Metallic accents

Premium taste goes with premium look. The metallic highlights of your SENSEO® coffee machine make it enjoyable not only for the

coffee it brews but also for the refinement it brings to your kitchen.

Two cups in less than a minute



With the SENSEO® coffeemaker you can have your perfect cup of delicious, freshly brewed coffee in approximately 30 seconds and two cups in less than a minute.

Volume select



The Volume Select function allows you to choose the desirable amount of coffee for the preparation of your black coffee or coffee specialty.

Adjustable spout



By raising or lowering the spout you can adjust your SENSEO® coffee machine to the size of your favorite cup or mug.

Extra-large water reservoir



The removable extra-large water reservoir of the coffeemaker has the capacity to accommodate 8 cups of coffee and therefore minimizes coffee preparation time.

Water-level feedback lights

The illuminating feedback lights of the 1 cup/2 cups buttons inform you at any time whether or not you have sufficient amount of water in the water reservoir to prepare your fresh SENSEO® coffee.

LCD display

The LCD display allows you to better visualize the volume control function and gives you feedback on when you need to decalcify your SENSEO® coffee machine.

Specifications

Weight and dimensions

- Product dimensions (L x D x H): 190 x 310 x 340 mm
- Product weight: 2.4 kg
- Maximum cup height: 97 - 117 mm
- Water tank capacity: 1.2 L
- Max capacity in cups of coffee: Up to 8 cups

Country of origin

- Country of origin: Poland

General specifications

- Ease of cleaning & maintenance: Dishwasher-safe

parts

Design specifications

- Color(s): Chrome silver

Technical specifications

- Cord length: 80 cm
- Voltage: 120 V
- Power: 1450 W
- Frequency: 60 Hz
- Black coffee brew volume: 3 to 10 oz
- Auto-off: 60 minute(s)