Register your product and get support at

### www.philips.com/welcome

PO217



## **PHILIPS**

## **PHILIPS**

: 飞利浦电动剃须刀

型号 : PQ217 额定电压 : 220V~ 额定频率 . 50Hz

额定输入功率: 1W 生产日期 : 请见产品本体



珠海经济特区飞利浦家庭电器有限公司 中国珠海市三灶镇琴石工业区 全国顾客服务热线: 4008 800 008

本产品根据国标 GB4706.1-2005, GB4706.9-2008

请妥善保管本使用说明书 发行日期: 07/12/2012

www.philips.com






4222.002.5449.1
































### **ENGLISH**

### ■ Introduction

Congratulations on your purchase and welcome to Philips! To fully benefit from the support that Philips offers, register your product at www.philips.com/welcome.

### General description (Fig. 1)

- 1 Protection cap
- Shaving heads
- Shaving unit
- Retaining frame
- Central spring of retaining frame
- Hair chamber
- On/off slide
- Front panel
- Charging light
- 10 Socket for small plug
- 11 Cleaning brush
- 12 Philips Cleaning Spray (Optional)
- 13 Small plug
- 14 Mains cord with plug
- 15 Cutter
- 16 Guard

### Important

Read this user manual carefully before you use the appliance and save it for future reference.

- Keep the appliance and the mains cord dry.
- This symbol means: Forbidden to clean under a running tap (Fig. 2).

### Warning

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Do not use the shaver or the mains cord if it is damaged.
- If the mains cord is damaged, always have it replaced with one of the original type in order to avoid a hazard.

#### Caution

- Use, charge and store the appliance at a temperature between 5°C and 35°C.
- Only use the mains cord supplied to charge the appliance.
- Only use the cleaning brush supplied.
- Make sure the cleaning brush remains

### Electromagnetic fields (EMF)

This Philips appliance complies with all standards regarding electromagnetic fields (EMF), If handled properly and according to the instructions in this user manual, the appliance is safe to use based on scientific evidence available today.

### **■**Charging

Make sure the shaver is switched off when you start to charge it.

When you charge the shaver for the first time or after a long period of disuse, let it charge continuously for 12 hours. Charging normally takes approx. 8 hours. Charge the appliance when the motor stops or starts running slower.

Do not leave the appliance connected to the mains for more than 24 hours.

- 1 Put the small plug in the shaver (Fig. 3).
- 2 Put the plug in the wall socket.
- The charging light goes on to indicate that the appliance is charging (Fig. 4).
- 3 Remove the plug from the wall socket and pull the small plug out of the shaver when the battery is fully charged (Fig. 5).

Note: The shaver does not run from the mains. When the battery is empty, you have to recharge the battery before you can use the shaver again.

Note: The light of the shaver does not change color and does not go out when the shaver is fully charged.

### Cordless shaving time

A fully charged shaver has a cordless shaving time of approximately 30 minutes.

### Using the appliance

The shaver cannot be used directly from the mains.

1 Remove the protection cap.

- 2 Push the on/off slide upwards to switch on the shaver (Fig. 6).
- Move the shaving heads over your skin. Make both straight and circular movements (Fig. 7).

Note: Shave on a dry face only. Do not use the shaver in combination with gel, foam or water.

Note: Your skin may need 2 or 3 weeks to get accustomed to the Philips shaving system.

- 4 Push the on/off slide downwards to switch off the shaver.
- 5 Clean the shaver after every shave (see chapter 'Cleaning and maintenance').
- 6 Put the protection cap on the shaver to prevent damage and to avoid dirt accumulation in the shaving heads (Fig. 8).

### Cleaning and maintenance

Never use scouring pads, abrasive cleaning agents or aggressive liquids such as petrol or acetone to clean the appliance.

Clean the shaver after every shave to guarantee better shaving performance. For the best cleaning result, we advise you to use Philips Cleaning Spray. Ask your Philips dealer for information.

### After every shave: shaving unit and hair chamber

- 1 Switch off the shaver, remove the plug from the wall socket and pull the small plug out of the shaver.
- 2 Clean the top of the appliance with the cleaning brush supplied (Fig. 9).
- 3 Pull the shaving unit straight up off the shaver (Fig. 10).
- 4 Clean the inside of the shaving unit with the cleaning brush (Fig. 11).
- 5 Clean the hair chamber with the cleaning brush (Fig. 12).
- 6 Put the shaving unit back onto the shaver (Fig. 13).

Every two months: shaving heads

Note: Do not use cleaning agents or alcohol to clean the shaving heads. Only use Philips Cleaning Spray.



- 1 Switch off the shaver, remove the plug from the wall socket and pull the small plug out of the shaver.
- 2 Pull the shaving unit straight up off the shaver (Fig. 14).
- To remove the retaining frame, turn the central spring clockwise (1). Then lift the retaining frame out of the shaving unit (2) (Fig. 15).
- 4 Lift the shaving heads out of the shaving unit. Remove and clean one shaving head at a time. Each shaving head consists of a cutter and a guard (Fig. 16).

Note: Do not clean more than one cutter and guard at a time, since they are all matching sets. If you accidentally mix up the cutters and guards, it may take several weeks before optimal shaving performance is restored.

- 5 Remove the guard from the cutter (Fig. 17).
- 6 Clean the cutter with the shortbristled side of the cleaning brush. Brush carefully in the direction of the arrows (Fig. 18).
- 7 Clean the guard with the long-bristled side of the cleaning brush (Fig. 19).
- 8 Put the cutter back into the guard after cleaning (Fig. 20).
- 9 Put the shaving heads back into the shaving unit (Fig. 21).
- 10 Put the retaining frame back into the shaving unit (1), and turn the central spring anti clockwise (2) (Fig. 22).
- 11 Put the shaving unit back onto the shaver (Fig. 13).

### **S**torage

Keep the appliance dry.
Use and store the appliance at a temperature between 5°C and 35°C.

- 1 Switch off the shaver.
- 2 Put the protection cap on the shaver after use to prevent damage and to avoid dirt accumulation in the shaving heads (Fig. 8).

### Replacement

Replace the shaving heads every two years for optimal shaving results.

Replace damaged or worn shaving heads with Philips shaving heads only (HQ4 for China or HQ56 for the rest of the world). For instructions on how to remove the shaving heads, see chapter 'Cleaning and maintenance', section 'Every two months: shaving heads'.

#### Accessories

To retain the top performance of your shaver, make sure you clean it regularly and replace its shaving heads at the recommended time.

### Shaving heads

 We advise you to replace your shaving heads every two years. Always replace them with Philips shaving heads only (HQ4 for China or HQ56 for the rest of the world) (Fig. 23).

### Cleaning

- Use Philips Cleaning Spray to clean the shaving heads thoroughly.

#### Environment

- Do not throw away the appliance with the normal household waste at the end of its life, but hand it in at an official collection point for recycling. By doing this, you help to preserve the environment (Fig. 24).
- The built-in rechargeable battery contains substances that may pollute the environment. Always remove the battery before you discard and hand in the shaver at an official collection point. Dispose of the battery at an official collection point for batteries. If you have trouble removing the battery, you can also take the shaver to a Philips service centre. The staff of this centre will remove the battery for you and will dispose of it in an environmentally safe way (Fig. 25).

# Removing the rechargeable battery

Only remove the rechargeable battery if it is completely empty.

1 Remove the plug from the wall socket and pull the small plug out of the shaver.

- 2 Let the shaver run until it stops, undo the screw on the back of the shaver (1) and lift the back panel off the shaver (2) (Fig. 26).
- Remove the rechargeable battery (Fig. 27)

Do not connect the shaver to the mains again after you have removed the battery.

### Guarantee and support

If you need information or support, please visit **www.philips.com/support** or read the separate worldwide guarantee leaflet.

#### **Guarantee restrictions**

The shaving heads (cutters and guards) are not covered by the terms of the international guarantee because they are subject to wear:

### Troubleshooting

This chapter summarises the most common problems you could encounter with the appliance. If you are unable to solve the problem with the information below, contact the Consumer Care Centre in your country.

| Problem  | Possible cause   | Solution  |
|--|--|---|
| The shaver<br>does not<br>shave as<br>well as it<br>used to<br>do. | The shaving heads are dirty. You have not cleaned the shaver well enough or you have not cleaned it for a long time. | Clean the<br>shaver thor-<br>oughly before<br>you continue<br>shaving. See<br>chapter<br>'Cleaning and<br>maintenance'.                           |
|  | Long hairs<br>obstruct<br>the shaving<br>heads.  | Clean the cutters and guards with the cleaning brush supplied. See chapter 'Cleaning and maintenance', section 'Every two months: shaving heads'. |

|   | The shaving heads are damaged or worn.  | Replace the<br>shaving heads.<br>See chapter<br>'Replacement'.  |
|---|---|---|
| The shaver does not work when I push the on/off slide up-wards. | The battery is empty.   | Recharge<br>the battery.<br>See chapter<br>'Charging'.  |
| My skin is<br>irritated<br>after shav-<br>ing.                  | Your skin<br>needs time<br>to get<br>used to<br>the Philips<br>shaving<br>system. | Skin irritation<br>during the first<br>2-3 weeks of<br>use is pos-<br>sible. After this<br>period, the<br>skin irritation<br>usually disap-<br>pears.                 |
| The rotation speed of the shaving heads is lower than usual.    | Too much<br>dirt has<br>collected<br>in the<br>shaving<br>heads.                  | Clean the<br>shaving heads.<br>See chapter<br>'Cleaning and<br>maintenance'.  |
|   | The battery is empty  | Recharge<br>the battery.<br>See chapter<br>'Charging'.  |
| The appliance makes a strange noise.                            | Too much<br>dirt has<br>collected<br>in the<br>shaving<br>heads.                  | Clean the shaving heads. After cleaning, lubricate the central point on the inside of the guards with Philips Cleaning Spray. See chapter 'Cleaning and maintenance'. |
|   | The shaving heads are damaged or worn.  | Replace the shaving heads.<br>See chapter 'Replacement'.  |

Problem

**Possible** 

cause

Solution

### 简体中文

#### **一**

感谢您的惠顾,欢迎光临飞利浦! 为了您能充分享受飞利浦提供的支持, 请在 www.philips.com/welcome 上注册 您的产品。

### ■■基本说明 (图 1)

- 1 保护盖
- 2 剃须刀头
- 3 剃毛刀头部件
- 4 固定架
- 5 固定架的中央弹簧
- 6 毛发储藏室
- 7 开/关滑钮
- 8 前面板
- 9 充电指示灯
- 10 小插头的转换插座
- 11 清洁刷
- 12 飞利浦清洁喷雾剂(可选)
- 13 小插头
- 14 带插头的电源线
- 15 刀片
- 16 网罩

### ■■注意事项

使用产品之前,请仔细阅读本用户手册,并妥善保管以供日后参考。

#### 合除

- 保持产品和电源线干燥。
- 警告符号注释:禁止用在打开的水 龙头下进行清洗。(图 2)

#### 警告

- 肢体不健全、精神有障碍及缺乏相 关经验和知识的人(包括儿童)必 须在监护人的监督及指导下使用。
- 请照看好儿童,本产品不能用于 玩耍。
- 如果剃须刀或电源线已损坏,请勿 再使用。
- 电源软线不能更换,如果软线损坏,此器具(电源适配器)应废弃。如果电源软线损坏,则必须用原装型号替换,以免发生危险。

#### 注意

- 必须在 5 摄氏度至 35 摄氏度之间 的温度下使用、存放和为本产品 充电
- 仅使用随附的电源线为产品充电。
- 仅限使用随附的清洁刷。
- 确保清洁刷保持洁净。

### 电磁场 (EMF)

这款飞利浦产品符合关于电磁场 (EMF) 的相关标准。据目前的科学证明, 如果 正确使用并按照本用户手册中的说明讲 行操作,本产品是安全的。

### 

请确保开始充电前, 剃须刀电源已关

如果是第一次为剃须刀充电,或是长时 间未使用后充电, 应让其连续充电 12 小时。充电通常需要约 8 小时。 当马达停止运转或开始运转缓慢时, 应为产品充电。

### 不要将本产品与电源接通超过 24 小时。

- 1 将小插头插入剃须刀。(图 3)
- 2 将电源插头接入插座。
- ▶ 充电指示灯亮起,表示剃须刀正在 充电。(图 4)
- 3 电池充满后,从电源插座中拔下 电源插头,并从剃须刀上拔出小插 头。(图 5)

注意: 本剃须刀不能插电使用。当电池 电量耗尽时,请在再次使用剃须刀前为 电池充电。

注意: 剃须刀充满电后, 剃须刀的指示 灯不会改变颜色及熄灭。

### 不接电源的剃须时间

完全充电的剃须刀在不连接电源的情况 下最长可使用达 30 分钟。

### ■■使用本产品

剃须刀不能连在电源上直接使用。

- 1 取下保护盖。
- 2 向上推动开/关滑钮以接通剃须刀电 源。(图 6)
- 3 将剃须刀头在皮肤上移动。作直线 和迂回动作。(图 7)

注意: 仅限在干爽的面部剃须。请勿 将本剃须刀与凝胶、剃须泡沫或水结 合使用。

注意: 您的皮肤可能需要 2 到 3 周才 能适应飞利浦剃须系统。

- 4 向下推动开/关滑钮以关闭剃须刀电 源。
- 5 每次剃须后均应清洁剃须刀 (见"清洁和保养"一章)。

6 请盖上剃须刀保护盖,以防止损坏 剃须刀头并避免其内积聚灰尘。

### ■■清洁和保养■■■

不要使用钢丝球、研磨性清洁剂或腐 蚀性液体(例如汽油或丙酮)来清洁

每次剃须后均应清洁剃须刀, 以保证更 好的剃须效果。为了获得最佳的清洁效 果,建议您使用飞利浦清洁喷雾剂。 有关详情,请咨询飞利浦经销商。

### 每次剃须后:清洗剃须刀头部件和 胡茬储藏室

- 1 关闭剃须刀电源,从电源插座中拔 下电源插头,并从剃须刀上拔出小
- 2 用随附的清洁刷清洁产品顶部。
- 3 垂直向上拉动剃须刀头部件,将其 从剃须刀中拉出。(图 10)
- 4 用清洁刷清洁剃须刀头部件的内 侧。(图 11)
- 5 用清洁刷清洁胡茬储藏室。(图 12)
- 6 将剃须刀头组件重新安装到剃须刀 上。(图 13)

#### 每两个月: 清洁剃须刀头

注意: 请勿使用清洁剂或酒精来清洁剃 须刀头。只能使用飞利浦清洁喷雾剂。

- 1 关闭剃须刀电源,从电源插座中拔 下电源插头,并从剃须刀上拔出小 插头。
- 2 垂直向上拉动剃须刀头部件,将其 从剃须刀中拉出。(图 14)
- 3 要取下固定架,以顺时针方向旋转 中央弹簧 (1)。然后将固定架从剃须 刀头部件中提起并取出 (2)。 (图 15)
- 4 将剃须刀头从剃须刀头部件中提起 并取出。一次取下并清洁一个剃须 刀头。每个剃须刀头包含一组刀片 和网罩。(图 16)

注意: 不要同时清洁多组刀片和网罩, 因为它们都是相互匹配的。如果不小心 将刀片和网罩弄混,则需要数周时间才 能恢复产品的最佳剃须性能。

5 从刀片上卸下网罩。(图 17)

- 6 用清洁刷的短毛一侧清洁刀片。 按箭头方向小心地清洁。(图 18)
- 7 用清洁刷的长毛一侧清洁网罩。 (图 19)
- 8 清洁后,将刀片重新装回至网罩。 (图 20)
- 9 将剃须刀头重新放入剃须刀头部 件。(图 21)
- 10 将固定架放回剃须刀头部件内 (1), 并沿逆时针方向转动中央弹簧(2)。 (图 22)
- 11 将剃须刀头组件重新安装到剃须刀 上。(图 13)

### ■■存储■■

保持器具干燥。

必须在 5°C 至 35°C 之间的温度下使 用和存放本产品。

- 1 关闭剃须刀。
- 2 使用后请盖上剃须刀保护盖, 以防止损坏剃须刀头并避免其内积 聚灰尘。(图 8)

### ■■更換■■

每两年更换一次刀头以获得最佳的剃 须效果。

只能使用飞利浦剃须刀头(适用于中 国的 HQ4 或适用于世界其他各地的 HQ56) 更换损坏或磨损的剃须刀头。 有关如何拆卸剃须刀头的说明, 请参 阅"清洁和保养"一章中的"每两个 月: 清洁剃须刀头"部分。

为了保持剃须刀的最佳性能, 请确保定 期清洁并在推荐的时间更换剃须刀头。

### 剃须刀头

建议您每两年更换一次剃须刀头。 务必仅使用飞利浦剃须刀头(适用 干中国的 HQ4 或适用干世界其他 各地的 HQ56) 进行更换。(图 23)

### 清洁

使用飞利浦清洁喷雾剂彻底清洁剃 须刀头。

#### ----环保--

- 弃置产品时, 请不要将其与一般生 活垃圾堆放在一起; 应将其交给官 方指定的回收点。这样做有利于环 保。(图 24)
- 内置充电电池包含可能会污染环境 的物质。丢弃剃须刀时,一定要将

电池取出,并将剃须刀送到官方指 定的回收站。到官方指定的电池回 收站处理电池。如果您在取出电池 时遇到问题, 您也可以将剃须刀送 至飞利浦维修中心。维修中心的员 工会帮您取出电池, 并以环保的方 式处理它。(图 25)

### 卸下充电电池

### 电池电量完全耗尽后方可取出充电电池。

- 1 从电源插座上拔下插头,并从剃须 刀上拔出小插头。
- 2 让剃须刀一直运行直到停止, 拧开剃须刀背面的螺丝钉 (1) 并将后面板从剃须刀上卸除 (2)。 (图 26)
- 3 取出充电电池 (图 27)

取出电池之后,不要再将剃须刀与电源 连接在一起。

### ■■保修和支持■■■

如果您需要信息或支持, 请访问 www.philips.com/support 或阅读单独的 全球保修卡。

### 保修条款

由于剃须刀头(刀片和网罩)属于易磨 损物品, 因此不在国际保修条款的涵盖 范围之列。

### ■■故障种类和处理方法■

本章归纳了使用本产品时最可能遇到的 问题。如果您无法根据下面的信息解决 问题,请联系您所在国家/地区的飞利浦 客户服务中心。

#### 问题 可能的 解决方法 原因 剃须刀头 在继续剃须 剃须刀的 之前,请先 剃须效果 变脏。您 没有将剃 没有以前 彻底清洗剃 须刀清洁 须刀。 干净,或 见"清洁和 长时间未 保养"一 清洁过剃 章。 须刀。

#### 问题 可能的 解决方法 原因 过长的胡 用随附的清 洁刷清洁刀 须堵塞了 剃须刀 片和网罩。 见"清洁和 保养"中 "每两个 月: 剃须刀 头"部分。 更换剃须刀 剃须刀头 已损坏或 头。见"更 磨损。 换"一章。 向上推动 电池已耗 给电池充 开/关滑钮 尽。 电。见"充 时剃须刀 电"一章。 不工作。 我在剃须 您的皮肤 在前 2-3 周 后出现皮 需要一定 的使用过程 肤讨敏。 的时间来 中. 可能会 适应飞利 出现皮肤过 浦剃须 敏。在此之 Л 后,皮肤过 敏诵常会消 失。 剃须刀头 剃须刀头 清洁剃须刀 的转速比 中积聚了 头。请参 平时慢。 太多的灰 阅"清洁和 保养" 尘。 一章。

# 电池已. 给电池充

|      | 耗尽   | 电。见"死电"一章。 |
|------|------|------------|
| 产品发出 | 剃须刀头 | 清洁剃须刀      |

奇怪的噪

音。

| /L3/2(/ ) 2 / ( | 1131 H 11312 (1) |
|-----------------|------------------|
| 中积聚了            | 头。清洁             |
| 太多的灰            | 后,用飞利            |
| 尘。              | 浦清洁喷雾            |
|                 | 剂润滑网罩            |
|                 | 内侧的中央            |
|                 | 点。请参             |
|                 | 阅"清洁和            |
|                 | 保美"              |

剃须刀头 更换剃须刀 已损坏或 头。见"更 磨损。 换"一章。

一章。