



Philips
Steam iron

Double anti-calc

GC2820

Built to perform, day after day

With new SteamGlide soleplate

For great results day after day, you want an iron that never lets you down. With its new SteamGlide soleplate, 2000 W for constant high steam output and Calc buster pills, this practical iron gives you value for money that lasts!

Powerful performance

- 2000 Watt enables constant high steam output

Comfortable ironing

- Drip-stop system keeps your garments spotless while ironing

Easy gliding on all fabrics

- SteamGlide soleplate is Philips premium soleplate

Longer lifetime

- The pills break down calc so you can flush away easily
- Calc clean slider to easily remove scale out of your iron

Easily removes creases

- Vertical steam for crease removal in hanging fabrics
- Steam boost up to 90 g for the most stubborn creases
- Continuous steam up to 30 g/min for better crease removal

PHILIPS

Specifications

Fast and powerful crease removal

- Soleplate: SteamGlide
- Continuous steam output: 30 g/min
- Power: 2000 W
- Spray
- Vertical steaming
- Steam boost: 90 g
- Variable steam settings

Easy to use

- Water tank capacity: 300 ml
- Drip-stop
- Cord freedom (swivel): 360 degree cord freedom
- Power cord length: 2 m

Technical specifications

- Voltage: 220 - 240 V
- Weight of iron: 1.2 kg
- Product dimensions: 29.5 x 11.6 x 19.5 cm

Calc management

- Calc clean solution: Double active calc clean
- Suitable for tap water

Comfortable ironing

- Cord length: 1.8 m

Highlights

SteamGlide soleplate

The SteamGlide soleplate is the best Philips soleplate for your steam iron. It has great scratch resistance, glides excellently and is easy to clean.

Steam boost up to 90 g

The iron's 90 g steam boost enables you to easily remove even the most stubborn creases.

Anti scale pills

After time calc builds up in your iron. This pill breaks down the calc into small pieces so you can calc clean your iron easily. This cleaning needs to take place once a month.

Calc clean slider

This steam iron can be operated with normal tap water, and the calc clean slider makes it easy to remove any built-up scale from your iron. To maintain the performance of your Philips steam iron, you should use this scale clean function once a month when using normal tap water.

2000 Watt

2000 Watt enables constant high steam output.

Up to 30 g/min of steam

Continuous steam up to 30 g/min for better crease removal.

Drip-stop system

Your Philips steam iron's Drip-Stop system lets you iron delicate fabrics at low temperatures without having to worry about stains from water droplets.

Vertical steam

Vertical steam for crease removal in hanging fabrics.

