

# PHILIPS

waterproof styler &  
shaver

StyleShaver

Pro



QS6140



## Express your style

Trim, style & shave - with one product

Create the exact look you want with Styleshaver. With just a flip of the wrist, this dual-ended electric beard trimmer and styler has everything you need to create a perfect beard style, 3-day beard, or a clean shave, even on tough beards

### Trim + style + shave

- Beard trimmer with 12 length settings from 0.5mm to 10mm
- Reversible trimmer: 32mm and 15mm sides for perfect details
- Dual shaver with trimmer shaves even the toughest beards

### Easy to use

- 100% waterproof for easy cleaning
- Battery light shows the battery status
- 2-year guarantee, worldwide voltage, no oil needed
- 50 minutes cordless power after 4 hour charge.
- Foldable stand for charging and storage

### Skin friendly performance

- Skin-friendly, high-performance trimmer blades



[asimpleswitch.com](http://asimpleswitch.com)



[asimpleswitch.com](http://asimpleswitch.com)

# Highlights

## Beard and stubble trimmer



A full size (32mm) Philips beard and stubble trimmer with 12 adjustable length settings from 0.5mm to 10mm makes it easy to get exactly the length you want. Turn the wheel to lock-in your perfect length setting. The durable metal trimmer with skin-friendly rounded edges guarantees a precise and even trim.

## Reversible trimmer



Take off the adjustable length comb, and there's a reversible precision trimmer underneath. One side is a 32mm high-performance trimmer. Turn it around, and there is a 15mm wide precision trimmer – perfect for getting into small spaces, like under your nose or around your mouth. It's designed to cut very close while still protecting your skin, and it's small size and angled design make it easy to see what you are doing for fine lines and details.

## Dual foil shaver with trimmer



The dual foil shaver makes it easy to clean up stubble around your beard, even on your neck. The mid trimmer catches longer, tougher hairs and the 2 floating foils shave everything else perfectly smooth.

## 100% waterproof



Shave or trim your beard where you want to, wet or dry. When you're done, just rinse it off under the tap.

## Battery light



Battery light glows light blue when full and blinks orange when 10 minutes remain.

## Built to last



All of our grooming products are built to last. They come with a 2 year worldwide guarantee, worldwide voltage compatibility, and they never need to be oiled.

## Skin-friendly high-performance



The steel blades of the electric shaver lightly brush against each other, so they sharpen themselves as you trim! The blades stay extra-

sharp to always cut hairs neatly and effectively, but have rounded blade tips and combs to prevent skin irritation.



[asimpleswitch.com](http://asimpleswitch.com)

## Philips Green Logo

Philips Green Products can reduce costs, energy consumption and CO2 emissions. How? They offer a significant environmental improvement in one or more of the Philips Green Focal Areas – Energy efficiency, Packaging, Hazardous substances, Weight, Recycling and disposal and Lifetime reliability.

# Specifications

## Service

2-year guarantee

## Accessories

Cleaning brush

## Create the look you want

**Styles:** Detailed styling, Short beard, Stubble look, Long beard, Moustache

## Cutting system

**Comb type:** Stubble, Beard

**Non-scratching teeth:** For more comfort

**Precision (size of steps):** by 0.5 mm

**Number of length settings:** 12

## Design

**Color:** Metallic lacquer

**Handle:** Rubber grip

## Ease of use

**Secured length settings**

**Wet & Dry:** 100 % waterproof for easy use and cleaning

**Zoomring:** Easily adjust length settings

**LED indicator:** Charging and battery level

## Power system

**Battery type:** Li-ion

**Charging time:** Quick charge, 4 hours

**Running time:** 50 minutes

