

PHILIPS

Beard trimmer

Beardtrimmer 3000

0.5mm precision settings

Full metal blades

60 min cordless use/1h charge

Lift & Trim system



BT3236/13



3-day beard made easy

Lift & Trim system for 30% fewer passes

This trimmer with the innovative Lift & Trim system lifts and captures more low-lying hairs for efficient, even trimming results. This way you will easily achieve the 3-day stubble, short beard or long beard look you want.

Easy even trimming

- Trims evenly and captures low-lying hairs
- Blades are double sharpened for faster trimming
- Skin-friendly blades for smooth skin

Easy to use

- 40 lock-in length settings, 0.5 - 20mm with 0.5mm precision
- Long beard comb for an even trim in longer lengths
- Cordless use for up to 60 mins
- Lights indicate when battery is low, empty, full or charging
- Simple maintenance
- Easy to grip
- Store and go

Built to last

- Warranty for purchase protection



asimpleswitch.com

Highlights

Lift & Trim system

Perfect for stubble, the Philips beard trimmer features our new Lift & Trim system: a comb that lifts and guides the hairs to the level of the blades for an even trim.

Full metal blades



This trimmer comes with twice-sharpened full metal blades that cut more hairs in every pass for faster trimming.

Skin-friendly blades



Designed to prevent scratches and irritation, the blades have rounded tips for smoother skin contact.

Zoomwheel - 40 length settings



The zoomwheel lets you choose from 0.5 to 10mm length settings with the precision comb, and from 10.5 to 20mm with the long beard comb, both with 0.5mm precision steps.

Long beard comb

The long beard comb allows you to maintain a long beard from 10.5 to 20mm, so that you don't need to trim to short lengths.

60 min corded/cordless use



Don't get tangled up in your stubble trimmer – a 1 hour charge provides up to 60 minutes of cordless grooming time. Or keep it plugged in for uninterrupted trimming.

Battery indicators

The battery indicators in this trimmer let you know what your battery status is: Low, empty, charging or full. This way, you can charge your trimmer on time and fully, so you won't end up with an empty battery in the middle of your trim.

Easy to clean

Detach the head of your Philips beard trimmer and rinse it under the tap for easy cleaning. Then dry it before you put it back on the appliance.

Ergonomic design



A fast trimmer that's comfortable to hold and use. So you can handle those hard-to-reach areas more easily.

Built to last

All of our grooming products are built to last. They come with a 2 year warranty, never need to be oiled and are compatible with any voltage worldwide.

Travel and storage pouch

The included travel pouch keeps everything together when you're at home, at the gym or on-the-go.



[asimpleswitch.com](https://www.asimpleswitch.com)

Philips Green Logo

Philips Green Products can reduce costs, energy consumption and CO2 emissions. How? They offer a significant environmental improvement in one or more of the Philips Green Focal Areas – Energy efficiency, Packaging, Hazardous substances, Weight, Recycling and disposal and Lifetime reliability.

Specifications

Cutting system

Precision (size of steps): By 0.5 mm

Range of length settings: 0.5 up to 20 mm

Cutter width: 32 mm

Cutting element: Full metal blades

Non-scratching teeth: For more comfort

Create the look you want

Number of length settings: 40 integrated length settings

Accessories

Comb: Lift & Trim system, Long beard comb

Pouch: Storage pouch

Maintenance: Cleaning brush

Power

Run time: 60 minutes

Charging: 1 hour full charge

Battery Type: NiMH

Automatic voltage: 100-240 V

Ease of use

Zoom wheel: Easily adjust length settings

Display: Battery low indicator, Battery empty indicator, Charging indicator

Cleaning: Rinseable attachments

Operation: Corded & Cordless use

Design

Handle: Ergonomic Easy Grip

Service

2-year guarantee

No oil needed

