

PHILIPS

13-in-1, Face, Hair
and Body

Multigroom series
9000

13 tools

Self-sharpening metal blades

Up to 180 min runtime

Showerproof



MG9720/90



Ultimate styling for face, hair & body

Prestige edition: 13-in-1 premium trimming set

Perfect your style with the Prestige Edition trimming set combining our Multigroom with 13 quality tools including self-sharpening metal blades and OneBlade Face+Body to precisely trim, edge and shave any length of hair for ultimate styling

Cutting performance

- Self-sharpening metal blades long-lasting
- Unique OneBlade technology

Versatility

- Trim and style your face, hair and body with 13 tools
- Nose trimmer gently removes unwanted nose and ear hair
- 7 combs for trimming your face, hair and body
- Edge it up
- Shave it off
- Click-on skin guard for sensitive areas

Easy to use

- Showerproof for convenient use in the shower and cleaning
- Run time: up to 180 minutes of cordless use per charge
- Each replaceable blade lasts 4 months
- Store it all to go

Highlights

Self-sharpening metal blades



Self-sharpening metal blades are incredibly long-lasting. Even after 5 years, they cut just like they did on day one.

Unique OneBlade technology



The Philips OneBlade has a revolutionary technology designed for facial styling and body grooming. It can style and shave any length of hair. Its dual protection system – a glide coating combined with rounded tips – makes shaving easier and comfortable. Its shaving technology features a fast-moving cutter (200x per second) so it's efficient – even on longer hairs.

13 tools for face, hair & body



This all-in-one trimmer conveniently trims and styles your facial hair, clips your hair and grooms your body.

Nose and ear trimmer



Remove unwanted nose and ear hair, easily and comfortably.

7 impact-resistant combs

2 stubble combs (1,2 mm), 1 adjustable (3-7mm), 3 hair combs (9,12,16 mm), 1 OneBlade body comb (3mm)

Edge it up



Get the perfect lines in seconds with the dual-sided blade, enabling you to see every hair you're cutting.

Shave it off



The OneBlade doesn't shave as close as a traditional blade, ensuring your skin stays comfortable. Go against the grain and easily shave off any length of hair with this sensitive skin hybrid styler.

Guard (Body)



Attach the skin guard for an extra layer of protection on sensitive areas.

Showerproof



This trimmer is designed to be water-resistant, so that you can use it comfortably in the shower and easily clean it under the tap.

Up to 180 minute of run time



The high-performance Lithium-Ion battery delivers up to 180 minutes of run time per every 3-hour full charge. A 5-minute quick charge delivers one full trim.

Durable OneBlade



Durable Philips OneBlade that you only need to replace every 4 months* for optimal performance.

Specifications

Create the look you want

Number of tools: 13 tools

Styling tools: Metal trimmer, Nose & ear trimmer, 3-7mm beard adjustable comb, 2 stubble combs, 3 hair combs, OneBlade handle, OneBlade extra blade, Click-on-skin guard, Click-on-body comb

Bodygroom/Hairclipping/Facial: Long beard, Short beard, Stubble look, Sharp lines, Detailed styling, Goatee

Cutting system

OneBlade Unique technology

Cutting element: Self-sharpening metal blades

Accessories

Maintenance: Cleaning brush, Storage cap
Pouch: Storage pouch

Power

Battery type: Lithium-ion
Charging: 3 hours full charge, 5min quick charge (Multigroom), 4 hours full charge (OneBlade)
Automatic voltage: 100-240 V
Run time: 180 minutes (Multigroom), 60 minutes (OneBlade)

Ease of use

Wet & Dry: Showerproof and easy cleaning
Display: Charging indicator, Battery low indicator

Maintenance free: No oil needed

Design

Handle: No-slip rubber grip

Service

2-year warranty

Replacement head: QP210, QP220, QP610, QP620, Replace every 4 months*

