

PHILIPS

Wet and dry electric shaver

Shaver series 7000
SensioTouch

DualPrecision & GyroFlex2D

50 min cordless use/1h charge

Trimmer, Pouch & Shaving head

RQ1155/82



Soft touch, smooth skin

The Philips SHAVER series 7000 gives a soft touch for a smooth shave. The GyroFlex 2D system adjusts easily to the curves of your face and shaves even the shortest stubble with its DualPrecision blades.

A close, comfortable shave

- Cutting slots & holes catch even the shortest hairs
- Super Lift and Cut blades raise hairs to cut closer
- 2-way flexing heads adjust easily to the curve
- Extra shaving head included

Skin friendly

- Aquatec seal for a comfortable dry & a refreshing wet shave
- Smooth, low-friction SkinGlide to minimise irritation

Easy to use

- Simply rinses clean
- 50 shaving minutes, 1 hour charge
- 2 level battery indicator with travel lock
- Perfect moustache and sideburn trimming
- Charging stand keeps your shaver fully charged and ready
- 2-year guarantee, worldwide voltage and replaceable blades



asimpleswitch.com

Highlights

Dual Precision blades



DualPrecision blades comfortably shave both long hairs and short stubble. 1. Slots cut long hairs. 2. Holes cut stubble

Super Lift and Cut



The dual blade system built into the Philips electric shaver lifts hairs to cut comfortably below skin level for a closer shave.

GyroFlex 2D



GyroFlex 2D contour-following system of the shaver adjusts easily to the curves of your face, minimizing pressure and irritation for a close shave.

Aquatec Wet and Dry



The Aquatec wet & dry seal of the electric shaver lets you choose how you prefer to shave. You can get a comfortable dry shave or a refreshing wet shave using a shaving gel or foam for extra skin comfort.

Fully washable shaver



Simply pop the heads open, and rinse thoroughly under the tap.

SkinGlide



The low-friction SkinGlide shaving surface of the electric shaver slides smoothly along your skin for a close easy shave.

Cordless use - 50 mins



An energy-efficient, powerful lithium-ion battery gives you more shaves per charge. Charge it for an hour and you'll have up to 50

minutes of shaving time. Charge it for 3 minutes and you'll have enough power for one shave.

Included: Extra shaving head



Within two years your shaver heads cut 9 million hairs on your face. Replace the shaving head every 2 years and get back to 100% performance.

2 level battery indicator



The multi-level LED display shows when the battery is low, when you need a new head and when the travel lock is on. Travel lock prevents the product from turning on by accident. Press any button for 3 seconds to activate the travel lock, so the product doesn't get turned on accidentally. A red lock symbol shows when the travel lock is on.



asimpleswitch.com

Philips Green Logo

Philips Green Products can reduce costs, energy consumption and CO2 emissions. How? They offer a significant environmental improvement in one or more of the Philips Green Focal Areas – Energy efficiency, Packaging, Hazardous substances, Weight, Recycling and disposal and Lifetime reliability.

Specifications

Shaving Performance

Contour following: GyroFlex 2D contour following

Shaving system: DualPrecision System, Super Lift & Cut technology

SkinComfort: SkinGlide

Styling: Skin friendly precision trimmer

Ease of use

Charging: 1 hour, Rechargeable, Quick charge 3 min for 1 shave

Shaving time: 50 minutes

Display: 2 level battery indicator, Battery low

indicator, Charge indicator, Travel lock, Quick charge indication

Cleaning: Washable

Design

Finishing: Brushed chrome deco ring

Accessories

Extra shaving head included: RQ11

Maintenance: Cleaning brush, Protective cap

Stand: Foldable charging stand

Pouch: Soft pouch

Power

Battery Type: Lithium-ion

Automatic voltage: 100-240 V

Service

2-year guarantee

Replacement head: Replace every 2 yrs with RQ11

