PHILIPS

Wet and dry electric shaver

Shaver series 7000

SkinGlide Rings GentlePrecisionPRO Blades SmartClick precision trimmer Shave gel & after shave balm



S7311/66

Face shave & care

Philips & NIVEA MEN: a winning team for your skin

The Philips series 7000 protects against the key signs of skin irritation. Together with the NIVEA MEN sensitive shave gel and sensitive after shave balm you can enjoy a smooth and comfortable shave for your sensitive skin.

Designed for maximum skin comfort

- SkinGlide rings with anti-friction coating for smooth glide
- 5 direction flex heads follow contours with less pressure
- Aquatec gives you a comfortable dry or refreshing wet shave
- Sensitive Shaving Gel protects skin from irritations
- Sensitive After Shave Balm instantly soothes irritation

A close and smooth shave

• Blades protect skin and cut close even with 3-day stubble

Easy to use

- Intuitive display with 1-level battery indicator
- 50 minutes of cordless shaving
- Shaver can be rinsed clean under the tap
- Comes with a 2-year guarantee

Get the most out of your shaver

· SmartClick precision trimmer for mustache and sideburns







Highlights

SkinGlide rings



Experience a more comfortable shave with anti-friction SkinGlide rings coated with microspheres. Thousands of tiny glass-like rounded spheres reduce friction and surface resistance between the shaver and the skin. This gives the shaver a smooth, easy glide and helps protect against skin irritation.

GentlePrecision PRO blades



Our updated cutting system has skin protection technology, designed to only cut hair not skin. V shaped blades guide the skin away from the blades for a close smooth shave – even on 3– day stubble.

5-direction Dynamic Flex Heads



Our shaver heads flex easily in 5 directions, gently following all the contours of the face and neck. Less pressure is needed to shave closely and skin stress is minimized.

Aquatec Wet & Dry



Adapt your shave routine to your needs. With the Aquatec Wet & Dry, you can go for a comfortable dry shave or a refreshing wet shave. You can shave with gel or foam even under the shower.

1 level battery indicator



The intuitive display shows relevant information, enabling you to get the best performance out of your shaver: 1-level battery indicator - cleaning indicator - battery low indicator - replacement head indicator - travel lock indicator

50 minutes of cordless shaving



The energy-efficient, powerful lithium-Ion battery system gives you two convenient options: Charge it for an hour for up to 50 minutes of shaving time, or a quick charge for one full shave. All Shaver series 7000 models are designed to operate only in cordless mode to ensure safety in wet environments.

SmartClick Precision Trimmer



Finish your look with the click-on precision trimmer. It's ideal for maintaining your mustache and trimming your sideburns.



iF DESIGN AWARD 2016

Shaver series 7000iF DESIGN AWARD 2016



asimpleswitch.com

Philips Green Logo

Philips Green Products can reduce costs, energy consumption and CO2 emissions. How? They offer a significant environmental improvement in one or more of the Philips Green Focal Areas – Energy efficiency, Packaging, Hazardous substances, Weight, Recycling and disposal and Lifetime reliability.



reddot award 2016 winner

Red Dot Award 2016: Winner

Shaver series 7000Red Dot Award 2016: Winner

Specifications

Shaving Performance

Shaving system: GentlePrecisionPRO Blades Contour following: 5-direction DynamicFlex Heads

SkinComfort: SkinGlide Rings, SkinProtection System, AquaTec Wet & Dry

Accessories

SmartClick: Precision trimmer

Pouch: Travel pouch

Facial care products included: Sensitive Shaving Gel, Sensitive After Shave Balm, Face Towel

Power

Battery Type: Lithium-ion Run time: 50 min / 17 shaves Charging: 1 hour full charge, Quick charge 5 min for 1 shave Automatic voltage: 100-240 V Max power consumption: 5.4 W Stand-by power: 0.15 W

Ease of use

Display: 1 level battery indicator, Battery low indicator, Cleaning indicator, Replace shaving heads indicator, Travel lock indicator

Cleaning: Fully washable Wet & Dry: Wet and dry use Operation: Cordless use, Unplug before use

Design

Handle: Ergonomic grip & handling Frame color: Ocean blue Front color: Ceramic white

Service

2-year guarantee Replacement head: Replace every 2 yrs with SH70

© 2019 Koninklijke Philips N.V. All Rights reserved.

their respective owners.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or lssue date 2019-08-01 Version: 1.2.1

EAN: 08 71010 38390 19

www.philips.com

