

# PHILIPS

## Hair clipper

### Hairclipper series 3000

Self-sharpening metal blades

13 length settings

45mins cordless use/8h charge



HC3525/13



## Constant power, easy haircut

### DuraPower technology: increase battery lifetime

With Hairclipper 3000 you achieve an easy, quick and even haircut, time after time. The DuraPower technology ensures a long-lasting battery performance, while the self-sharpening metal blades remain as sharp as day one without oiling

#### Performance

- DuraPower technology for a longer lasting battery life
- Self-sharpening metal blades

#### Precise length control

- Adjusts to different length settings
- Tames beards and stubble

#### Easy to use

- 45 minutes of cordless use after an 8-hour charge
- Ergonomic design for comfort and control
- Quick release blades for easy cleaning

#### Built to last

- The blades never need oiling
- Warranty for purchase protection

# Highlights

## DuraPower technology



The DuraPower technology lowers the friction on the blades, which protects the motor and the battery from being overloaded. This way, the battery life time of your clipper is increased.

## Self-sharpening metal blades



Self-sharpening metal blades are incredibly long-lasting. Even after 5 years, they cut just like they did on day one.

## 13 lock-in length settings



Cut your hair to the exact length you want. Just select one of 12 length settings between 1mm to 23mm at 2mm increments, or remove the comb for a close 0.5mm trim.

## Extra adjustable beard comb



Electric hair clippers to easily trim your beard or stubble, the adjustable beard comb has 12 length settings between 1mm to 23mm at 2mm increments, or you can remove the comb entirely for a close 0.5mm trim.

## Cordless & corded use



Use the clipper cordless for maximum power and freedom. Its powerful NiMH battery which provides up to 45 minutes of cordless power after 8 hour of charging.

## Comfortable grip



Philips clippers have a textured grip designed for easy handling, so you can cut your hair with control and in comfort.

## Easy to clean



Clean your electric hair clippers with ease. Simply click open the head to release and clean the blades.

## Zero maintenance



Clipping power that's easy to maintain—our blades never need oiling.

## 2-year worldwide guarantee



All of our grooming products are built to last. They come with a 2 year warranty, never need to be oiled and are compatible with any voltage worldwide.

# Specifications

## Cutting system

**Cutting element:** Self-sharpening metal blades

**Cutter width:** 41mm

**Number of length settings:** 13

**Precision (size of steps):** By 2mm

**Range of length settings:** From 0.5 to 23 mm

## Accessories

**Comb:** Adjustable hair comb, Extra adjustable beard comb

**Maintenance:** Cleaning brush

## Ease of use

**Cleaning:** Removable cutter, Washable blades

**Operation:** Corded & Cordless use

**Maintenance free:** No oil needed

## Power

**Run time:** 45 minutes

**Charging:** 8 hours full charge

**Battery type:** Ni-MH

**Automatic voltage:** 100-240 V

## Design

**Handle:** Ergonomic grip & handling

## Service

**2-year worldwide guarantee**

