

PHILIPS

Showerproof body groomer

Bodygroom series
7000

Skin contour system

Integrated comb, 3-11 mm

50 mins' cordless use/8 hr charge

Dual-sided design



TT2039/15



Powerful trim, precise shave

Everywhere below the neck

The ultimate all-in-one solution, the Series 7000 features an integrated trimmer on one side and a skin-friendly contour system on the other, for a comfortable and convenient trim or shave, anywhere below the neck.

Skin-friendly performance

- Adapts to the surface of your body for a precise shave
- Rounded tips and hypoallergenic foil for skin comfort
- Includes adjustable comb, trims hair from 3-11 mm

Easy to use

- 50 minutes cordless use after an 8-hour charge
- Easy to clean and use in or out of the shower
- Ergonomic grip for maximum control

Built to last

- 2-year guarantee, worldwide voltage, no oiling needed



asimpleswitch.com

Highlights

Skin contour system



The skin contour system catches and cut hairs of different lengths, without the need for multiple tools or skin contact with sharp edges. The bi-directional trimmers cut longer hairs, which are shaved by the foil for a closer result. The added flexibility of the contour system follows every angle and surface of your body for precisely the look you want.

Skin-friendly tips and foil



The skin comfort system features a hypoallergenic foil and rounded tips to protect your skin while shaving.

Integrated trimmer with comb



The integrated trimmer and adjustable comb with 5 length settings are designed to offer more power to cut even the thickest hair. To

maintain your desired hair length or get a natural look, adjust the comb to a length between 3 and 11 mm. You can use the shaving system on the other side for a closer result.

Rechargeable battery power



High-power NiMH battery for full-body use, with 50 minutes of cordless use after an 8-hour charge. The battery light indicates power status when the battery is low or full.

100% showerproof



Provides a comfortable and close result in and out of the shower. The body groomer is 100% showerproof, so you can simply rinse it clean when you've finished. For longer hair, trimming performance may be better on dry hair.

Ergonomic grip



The rubber grip is designed to ensure optimal handling even when wet, for better control during use, in or out of the shower.

Built to last



All of our grooming products are built to last. They come with a 2-year worldwide guarantee and worldwide voltage compatibility, and they never need to be oiled.



asimpleswitch.com

Philips Green Logo

Philips Green Products can reduce costs, energy consumption and CO2 emissions. How? They offer a significant environmental improvement in one or more of the Philips Green Focal Areas — Energy efficiency, Packaging, Hazardous substances, Weight, Recycling and disposal and Lifetime reliability.

Specifications

Cutting system

Cutter width: 32 mm

Shaving element: Foil with two pre-trimmers

Trimming element: Integrated

Skin comfort: Skin contour system

Create the look you want

Number of length settings: 5 integrated length settings

Ease of use

Wet and Dry: Fully washable, Showerproof and easy cleaning

Secured length settings

Operation: Cordless use

Maintenance-free: No oil needed

Design

Handle: Ergonomic grip and handling

Power

Battery type: Ni-MH

Run time: 50 minutes

Charging: 8 hours full charge

Accessories

Stand: Charging stand

Service

2-year worldwide guarantee

