

Philips Shaver series 5000 Wet and dry electric shaver

MultiPrecision Blade System

5-direction Flex Heads SmartClick precision trimmer SmartClean System

S5572

# Clean & close, Fast shave

# Protects 10X better versus a regular blade\*

The Shaver Series 5000 adds speed to your morning routine with a fast, MultiPrecision Blade System and fully washable heads.

#### Get the most out of your shaver

- · Click-on trimmer for perfect mustache and sideburn trimming
- Keep your shaver like new with SmartClean

#### A comfortable and close end result

- Blades raise then cut long and short hairs for a fast shave
- Heads flex in 5 directions for a fast close shave
- · Get a comfortable dry or refreshing wet shave with Aquatec
- · A rounded head profile glides smoothly protecting your skin

### A comfortable shave

• Shave through dense parts of beard with 20% more power

#### Easy to use

- 50 minutes of cordless shaving
- 1-hour charging time
- · 3-level battery and travel lock Indicators
- Shaver can be rinsed clean under the tap



# Highlights

# SmartClick precision trimmer



Click on our skin-friendly precision trimmer to finish your look. It's ideal for maintaining your mustache and trimming your sideburns.

# MultiPrecision Blade System



Get a shave that's fast and close. Our MultiPrecision Blade System raises and cuts all hairs and remaining stubble – all in a few strokes.

#### Turbo+ mode



Shave even faster through dense parts of your beard with the 20% extra power boost you get by activating Turbo+ mode.

# **5-direction Flex Heads**



5-direction Flex Heads with 5 independent movements ensure close skin contact for a fast and close shave even on neck and jaw line.

### 50 minutes of cordless shaving



You'll have 50+ minutes of running time – that's about 17 shaves – on a one-hour charge. This shaver only operates in cordless mode.

### 1-hour charging time



Shave longer with every charge, thanks to our powerful energy-efficient, long-lasting lithiumion battery. Do a quick charge for 5 minutes and you'll have enough power for one shave. Aquatec Wet & Dry



Choose how you prefer to shave. With the Aquatec Wet & Dry seal, you can opt for a quick yet comfortable dry shave. Or you can shave wet – with gel or foam – even under the shower.

# LED display

The intuitive display shows relevant information, enabling you to get the best performance out of your shaver: - 3-level Battery Indicator - Cleaning Indicator - Battery Low Indicator - Replacement Head Indicator -Travel Lock Indicator

### One touch open



Simply pop the heads open, and rinse thoroughly under the tap.

# SmartClean System



At the touch of a button, SmartClean cleans, lubricates and charges your shaver, keeping it performing at its best.

# Specifications

#### **Shaving Performance**

- SkinComfort: SkinProtection System, AquaTec Wet & Dry
- Shaving system: MultiPrecision Blade System, Super Lift & Cut Action
- Contour following: 5-direction Flex Heads
- Turbo+ mode: Shave with 20% extra power

#### Ease of use

- Display: 3 level battery indicator, Battery low indicator, Charging indicator, Cleaning indicator, Replace shaving heads indicator, Travel lock indicator
- Cleaning: Fully washable
- Operation: Cordless use, Unplug before use

### Power

- Battery Type: Lithium-ion
- Run time: 50 min / 17 shaves

- Charging: 1 hour full charge, Quick charge 5 min for 1 shave
- Automatic voltage: 100-240 V
- Max power consumption: 9 W
- Stand-by power: 0.1 W

#### Design

- Handle: Ergonomic grip & handling
- Color: Base Blue Super Nova Silver

#### Service

- 2-year guarantee
- Replacement head: Replace every 2 yrs with SH50

#### Accessories

- SmartClick: Precision trimmer
- SmartClean: Cleans, Charges, Lubricates, Cleaning cartridge (included)



Issue date 2019-09-30 © 2019 Koninklijke Philips N.V. All Rights reserved. Version: 1.0.1 Specifications are subject to cha

All Rights reserved. Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

www.philips.com

12 NC: 0000 041 02241 EAN: 87 10895 68541 2 \* Protects 10X better versus a regular blade - test done in Germany 2015, after 21 days acclimation

2015, after 21 days acclimation \* 20% more power - compared to not using Turbo+ mode