

# PHILIPS

do it yourself hair  
clipper

Easy Reach 180°

Pro



QC5580/13



## Shave your own head

The unique 180° rotating head makes it easy to reach even the most difficult spots, so you can give yourself a perfectly even and precise haircut every time. Or, click on the head shave attachment for a completely smooth finish.

### Easy-reach design

- 180° rotating head for easy reach.
- Head shave attachment for a perfectly smooth finish.

### Performance

- 14 easy lock-in length settings from 0 to 15 mm.
- Precision comb for a short buzz style.
- Up to 60 minutes of cordless power after an 1-hour charge.
- 2-year guarantee, worldwide voltage

### Easy to use

- Rounded tips and combs prevent skin irritation
- Self-sharpening blades
- Corded and cordless use
- Rubber grip for maximum control
- Battery light shows the battery status
- Fully washable for easy cleaning



[asimpleswitch.com](http://asimpleswitch.com)

# Highlights

## 180° rotating head



The rotating head gives you total control over the clipper's angle, so you can turn the head to reach even the most difficult areas with ease.

## Head shave attachment



Get a perfectly smooth shave without nicks or cuts. Simply clip on the head shave attachment for a flawless finish every time.

## 14 lock-in length settings



Turn the integrated zoom wheel beneath the clipper's head to select and lock in the length setting you want. Two combs provide length settings from 1mm to 15mm, with precisely 2mm between each length. Use the special precision comb for buzz cut...or use the clipper without a comb for a close 0.5mm trim.

## Precision comb



Extra precision for the extra short hairstyles with a dedicated comb (lengths setting from 0.5mm to 3mm, with 0.5 mm steps).

## Skin-friendly



The rounded edges on the blades and combs are designed to avoid scratching the skin for a more comfortable trim.

## Corded & powerful cordless use



Use it cordless or plugged in.

## Self-sharpening blades



The self-sharpening, stainless steel blades stay sharp longer and ensure top cutting performance.

## NiMh power



Use with or without cord for flexibility. The powerful NiMh battery lasts up to 60 minutes after a 1-hour charge. A quick 10-minute charge gives you 10 minutes of clipping time, so it's always ready when you are.

## Battery light



Battery light glows white when full and blinks orange when 10 minutes remain.



[asimpleswitch.com](http://asimpleswitch.com)

## Philips Green Logo

Philips Green Products can reduce costs, energy consumption and CO2 emissions. How? They offer a significant environmental improvement in one or more of the Philips Green Focal Areas – Energy efficiency, Packaging, Hazardous substances, Weight, Recycling and disposal and Lifetime reliability.

# Specifications

## Cutting system

Cutter width: 41 mm

Number of length settings: 14

Range of length settings: 0-15mm

Precision (size of steps): By 2mm mm

Cutting element: Stainless steel blades

Balder attachment: 0 mm

Big comb: 3-15mm

Precision comb: 1-3 mm

## Ease of use

Zoom wheel

Cleans under the tap

Adjustable guide combs

Display: Charging indicator

## Power system

Battery type: NiMH

Charging time: 1 hour

Running time: up to 60 minutes

Usage: Corded/cordless

## Design

Shape: Ergonomic design

## Accessories

Storage pouch

Cleaning brush

Balder attachment

Oil in pack

## Service

2-year worldwide guarantee

