



Philips
Satinelle Ice

HP6493

Unique ceramic epilation system from Philips

Ice & massage for a more gentle hair removal

Thanks to the soothing properties of ice and an integrated massage system, the new Satinelle Ice significantly reduces the pain normally associated with epilation. The hypoallergenic ceramic disc system is also gentle on sensitive skin.

Advanced pain reduction system

- Click-on ice cooler
- Pivoting cooling head
- Distracts the negative sensation from epilation

Unique ceramic epilating head

- Hypo-allergenic ceramic epilating head
- Curved epilating head
- Higher rotation speed

Additional benefits

- Sensitive ice cooler
- Exfoliating body puff
- Additional shaving head
- New ergonomic design
- Two speed settings

PHILIPS
sense and simplicity

Specifications

Features

- Ceramic epilation system
- Pivoting Ice cooler
- Active massage system
- 2 speed settings

Technical Specifications

- Power Source: AC (Mains)
- Voltage: 100-240 V (50-60 Hz) Automatic Voltage Selection V
- Motor: DC-Motor 14 V
- Power Consumption: 6 W
- Number of discs: 25
- Number of catching points: 24
- RPM: Speed I: 2200, Speed II: 2700
- Pulling actions/second: Speed I: 880, Speed II: 1080

Accessories

- Detachable shaving head
- Delicate area ice cooler
- Insulation sleeve
- Exfoliation body puff
- Luxury storage pouch
- Cleaning brush

Weight and dimensions

- Packaging design: Fancy-box with 3D-window
- F-Box dimensions: 19,6 x 9,4 x 23,5cm (width x depth x height) mm
- Weight F-box: 733 g
- A-box dimensions: 56,6 x 19,6 x 25,1cm (width x depth x height) mm
- Weight A-box: 4708 g
- No. of pieces per A-box: 6 pcs

Highlights

Click-on ice cooler

The patented ice cooler soothes the skin reducing the unpleasant feeling of epilation. Its pivoting head follows every curve of your body for optimal cooling and less pain.

Pivoting cooling head

Follows the body's contours for maximum pain reduction during epilation and an immediate cooling and soothing effect on the skin afterwards.

Integrated massaging system

Works with the ice to distract from the sensation of epilation for even more effective pain relief.

Hypo-allergenic ceramic epilating head

Better skin care by reducing the risk of allergic skin irritation.

Curved epilating head

For improved grip on hair, ensuring that up to 95% of hairs are removed at the root in one stroke.

Higher rotation speed

For more effective hair removal.

Exfoliating body puff for less ingrown hairs

Reduces ingrown hair.

New ergonomic design

For easier handling.

2 speed settings

Speed 1 for fine hair, speed 2 for thicker hair.



Issue date 2009-06-10

Version: 2.1

© 2009 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com