

PHILIPS

Vacuum Beard Trimmer

Beardtrimmer series 7000

0.5mm precision settings

Self-sharpening metal blades

Up to 100 min use/ 1 hr charge

High performance vacuum system



BT7520/15



Less mess vacuum trimmer

Philips' No. 1 in tidy trimming

Trim your beard, moustache and sideburns while keeping tidy. The new Philips Vacuum Trimmer has an improved, high performance system with 50% stronger* airflow. It captures cut hair effectively, giving you a mess-free trim.

Less mess vacuum trimmer

- Optimized airflow for a mess-free trim

Even trimming results

- Trims evenly and captures low-lying hairs
- Self-sharpening metal blades are precise even without oiling
- Click-on precision trimmer for perfect edges and details

Easy to use

- 20 lock-in length settings, 0,5 - 10mm with 0,5mm precision
- LED display clearly shows your length setting
- See remaining battery life at a glance
- Up to 100 min runtime after a 1 hour charge, or plug it in
- Just empty the chamber and rinse the blades under water
- Warranty for purchase protection

Highlights

High performance vacuum system



The new Philips Vacuum Trimmer comes with 50% stronger, improved airflow*. The powerful vacuum captures up to 95% of cut hair**, giving you a mess-free trim.

Lift & Trim PRO system



Stubble doesn't stand a chance. The Lift&Trim Pro system captures all your low-lying hairs and lifts them up toward the blades for a precise cut – whilst still being an ideal trimmer for long beards too.

Self-sharpening metal blades



The stainless steel blades are double-sharpened, cutting even the thickest hair precisely. They sharpen themselves by lightly

brushing against each other, so no replacement or oiling is needed throughout your trimmer's lifetime.

20 lock-in length settings



Select your preferred trim length by simply turning the zoom wheel on the handle until the length you want is displayed from 0,5 - 10mm with 0,5mm precision. Your chosen length is now "locked in" for a perfectly even trim.

Precision trimmer



Trim your moustache or define details and edges in hard to reach areas with the click-on precision trimmer.

Digital LED display



Turn the zoom wheel to view your chosen length setting in mm on the LED display.

Up to 100 min Li-Ion power



The powerful Li-ion battery provides up to 100 minutes of cordless use after 1 hour charge. You can also use your trimmer plugged in or the quick-charge function gives you one full trim after just 5 minutes of charging.

3-level battery indicator



You can clearly see how much power is left. 3 simple bars show you the remaining power, and when the trimmer is charging.

Easy to clean



Once you are done trimming, simply remove the blades by pulling them up, rinse the blades and comb under the tap, empty the hair chamber and brush away any loose hairs with the added cleaning brush for long-lasting performance.

Specifications

Cutting system

Cutting element: Stainless steel blades

Range of length settings: 0.5 up to 10 mm

Precision (size of steps): By 0.5 mm

Create the look you want

Number of length settings: 20 integrated length settings

Ease of use

Zoom wheel: Easily adjust length settings

Display: Digital length settings, 3 level battery indicator

Cleaning: Rinseable blades and guards

Operation: Corded & Cordless use

Design

Color(s): Dark chrome

Power system

5 min quick charge

Power

Run time: Up to 100 minutes

Battery Type: Lithium-ion

Automatic voltage: 100-240 V

Service

2-year warranty

No oil needed

Accessories

Precision trimmer

Comb: 3mm precision comb, 5mm precision comb

Stand: Charging stand

Pouch: Travel pouch, Luxurious travel pouch

Maintenance: Cleaning brush

