

# PHILIPS

## hair clipper

45 min grooming

Precision: 3-41 mm



QC5330



## Always even haircuts

Get an even haircut every time with the contour-following comb. The length settings of the Philips hair clipper QC5330/15 are easy to select and lock into place. There are 21 length settings to choose from, ranging from 0.5mm to 41mm.

### Easy to use

- 2- year guarantee, worldwide voltage, no oil needed
- Pop-open head makes it easy to clean
- 45 minutes of cordless use after an 8-hour charge
- Battery light shows the battery status

### Performance

- High-performance self-sharpening steel blades

### Always even haircuts

- 21 locking length settings from 0.5mm to 41mm
- Contour-following comb follows every curve of your head.

# Highlights

## 21 locking length settings

Two adjustable combs provide length settings from 3mm to 41mm, with precisely 2mm between each length. Or you can use it without a comb for a close 0.5mm trim.

## Battery light

Battery light glows green when full.

## Built to last

All of our grooming products are built to last. They come with a 2 year worldwide guarantee, worldwide voltage compatibility, and they never need to be oiled.

## Easy to clean

Simply pop the head open and use the included cleaning brush to sweep away the loose hairs.

## Follows every curve

Gently follows the contours of your head for a fast, even and comfortable haircut.

## Powerful cordless

Use it cordless or plugged in. You'll have 45 minutes of cordless power after 8 hours of charging.

## Self-sharpening steel blades

The steel blades lightly brush against each other, so they sharpen themselves as you trim! The blades stay extra-sharp to always cut hairs neatly and effectively, but have rounded tips to protect your skin.

# Specifications

## Service

2-year worldwide guarantee

## Accessories

Cleaning brush

## Cutting system

Cutter width: 41 mm

Number of length settings: 20

Precision (size of steps): by 2 mm

Range of length settings: 3-41 mm

Maintenance free - No Oil needed

Self-sharpening stainless steel blades

## Design

Easy grip: Side panels

Shape: Ergonomic

## Ease of use

Adjustable guide combs

Display: Charging indicator

## Power system

Battery type: NiMH

Charging time: 8 hours

Running time: 45 minutes

