



Philips Satinelle
Epilator

HP6407/22

Satinelle Soft

Gentle epilator with pivoting massage system

This compact Satinelle Soft has a pivoting massage system, which relaxes your skin and eases the sensation of epilation. It is detachable for easy cleaning.

Extra comfort with pivoting massage

- Pivoting massage system

Smooth skin for weeks

- Unique Philips epilating system

PHILIPS
sense and simplicity

Specifications

Features

- Pivoting massage system
- Metal epilating system
- 2 speed settings

Technical Specifications

- **Power Source:** AC (mains)
- **Voltage:** 100-120 V
- **Motor:** DC type
- **Power Consumption:** 3 W
- **Number of discs:** 21
- **Number of catching points:** 20
- **RPM:** speed I: 1900 min, speed II: 2200 min
- **Pulling actions/second:** speed I: 600, speed II: 733

Accessories

- Cleaning brush

Weight and dimensions

- **Packaging design:** Blister
- **Blister dimensions:** 13.50 x 8.00 x 21.59 cm
- **Weight blister:** 0.45 kg
- **No. of pieces per A-box:** 4 pcs
- **A-box dimensions:** 39.40 x 29.60 x 16.00 cm
- **Weight A-box:** 2.40 kg

Product highlights

Minimising the pain of epilation

The pivoting massage system relaxes your skin and eases the sensation of epilation. It is detachable for easy cleaning.

Unique Philips epilating system

The unique Philips Epilating System pulls out the hairs by the root, leaving your skin smooth and stubble-free for weeks. The hairs that do grow back are soft and thin.



Issue date 2009-02-16

Version: 4.2

© 2009 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com