



Philips Philips 5400
Series
Fully automatic
espresso machines

- 12 Beverages
- LatteGo milk solution
- Chrome
- TFT display

EP5447

12 delicious fresh bean coffees, easier than ever

LatteGo, the fastest to clean milk system ever*

Easily make aromatic coffee varieties like Espresso, Coffee, Cappuccino and Latte Macchiato at the touch of a button. LatteGo tops milk varieties with silky smooth froth, is easy to set up and can be cleaned in as little as 15 seconds*

A variety of coffees customized to your taste

- Easy selection of your coffee with the intuitive display
- Adjust aroma and volume with the coffee customizer
- Silky smooth milk froth thanks to high speed LatteGo system
- Your perfect cup, every time, thanks to 4 user profiles
- Enjoy 12 coffees at your fingertips, including café au lait

High quality coffee from fresh beans

- 20,000 cups of finest coffee with durable ceramic grinders
- The perfect temperature, aroma and crema cup after cup**
- Easily adjust to your taste with 12-step grinder levels
- Even more flavor thanks to the extra shot function

Effortless use and cleaning for everyday enjoyment

- Easy cleaning thanks to fully removable brew group
- Up to 5000 cups*** without descaling thanks to AquaClean
- Premium machine, elegantly designed for your kitchen

PHILIPS

Fully automatic espresso machines
12 Beverages LatteGo milk solution, Chrome, TFT display

EP5447/94

Highlights

12 delicious coffees



Every moment has its own kind of coffee to enjoy. From powerful espresso to indulgent cappuccino, your fully automatic espresso machine delivers a perfect in-cup result without any fuss in no time.

LatteGo milk system



Top your coffee off with a silky-smooth layer of milk froth. By using cyclonic frothing technology, LatteGo releases a powerful stream of microbubbles at a speed of 394 metres per second, creating a rich and dense milk foam.

Intuitive display



There's little standing between you and your next delicious cup of coffee with our easy-to-use display. In a few steps you can customize your fresh-bean flavor and flow smoothly from craving to cup.

Coffee customizer



Make any coffee your own with the coffee customizer's easily adjustable settings for intensity, coffee and milk length.

User profiles

Enjoy coffee you love the same way every time with four user profiles that store your customized recipes. With an extra guest profile, your visitors can savor a coffee exactly the way they like, without changing yours.

Extra shot function



Boost your drink's intensity with the coffee customizer's extra-shot feature, which adds powerful flavor without the bitterness.

Perfect temperature and aroma



The Aroma Extract system intelligently strikes the optimum balance between brewing temperature and aroma extraction by keeping

the water temperature between 90 and 98°C, while regulating the water flow rate, so you can enjoy delicious coffees.

12-step grinder adjustment



Our durable ceramic grinders can be adjusted in 12 steps, so you can turn your beans into anything from ultra-fine powder to coarse grindings.

100% ceramic grinders



Bring out the full flavor of your coffee with our hard-wearing ceramic grinder. Our sharp-edged grinders extract the best aroma and flavour from your beans. Made from 100% ceramic material which ensures they last for at least 20,000 cups, from coarse to ultra-fine.

Specifications

Country of origin

- Designed in: Italy
- Made in: Romania

Customization

- Aroma Strength Settings: 5
- Coffee and Milk Length: Adjustable
- Grinder Settings: 12
- Pre Brew Aroma control
- User Profiles: 4, Guest
- Temperature settings: 3

Variety

- Beverages: Espresso, Coffee, Americano, Cappuccino, Latte Macchiato, Flat white, Café au Lait, Caffè Latte, Caffè crema, Ristretto, Espresso Lungo, Travel mug function, Frothed milk, Hot water
- Coffee Powder Option
- Double Cup
- Milk Double Cup: No

Other features

- Removable brew group
- Aroma Seal
- Guided descaling
- AquaClean

Accessories

- Included: Measuring scoop, Water hardness test strip, AquaClean filter, Grease tube, LatteGo storage lid

Technical specifications

- Color(s): Black
- Voltage: 230 V
- Cord length: 100 cm
- Frequency: 50 Hz
- Capacity milk carafe: 0.26 L
- Capacity water tank: 1.8 L
- Capacity waste container: 12 servings
- Coffee bean capacity: 275 g
- Weight of product: 8 kg
- Waste container: Frontal access
- Water tank: Frontal access
- Filter compatibility: AquaClean
- Pump pressure: 15 bar
- Finishing: Chromed
- Product dimensions: 246x372x433 mm

General specifications

- Adjustable spout height: 85 - 145 mm
- Milk Solution: LatteGo
- Ease of cleaning & maintenance: AquaClean filter compatible
- Dishwasher safe parts: Drip tray, LatteGo
- Type of display: TFT

Service

- 2-year guarantee

Sustainability

- ECO setting
- Power consumption brewing: 1500 W
- Recyclable packaging material: > 95%



Issue date 2023-08-04

Version: 5.5.1

UPC: 0 75020 09517 6

© 2023 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com

* Based on consumer testing in Germany comparing leading One touch (Coffee + Milk) Full Automatic Espresso Machines (2018).

**Based on 70-82 °C.

***Based on 8 filters replacement as indicated by the machine. Actual number of cups depends on selected coffee varieties, rinsing and cleaning patterns.