



Philips PerfectCare Silence
Steam generator iron

Max 6.5-bar pressure

Up to 350 g steam boost
Carry lock
1.5 l detachable water tank



GC9550/02

Ultra fast and quiet ironing

Ultra fast and quiet ironing

Enjoy ironing with family around or while watching TV without being disturbed by the noise. Philips PerfectCare Silence steam generator iron combines powerful steam and fast ironing with quiet operation.

Fast and powerful ironing

- Descale your appliance effectively and easily to prolong its lifespan
- Automatically turned off for safety and energy saving
- 1.5 L detachable water tank, up to 2 hours of ironing
- New SteamGlide soleplate is Philips premium soleplate
- Lock your iron securely to the base station
- Steam boost up to 350 g
- Up to 6.5 bar pressure

Carefree ironing, no temperature setting required

- Silent steam technology: Powerful steam with minimum sound
- Iron everything from jeans to silk with no temperature setting required
- Safe to leave the hot soleplate on the ironing board

PHILIPS

Steam generator iron
Max 6.5-bar pressure Up to 350 g steam boost, Carry lock, 1.5 l detachable water tank

GC9550/02

Highlights

Silent steam technology



Enjoy ironing with family around or while watching TV, without being disturbed by the noise of the steam. Silent steam technology delivers quiet yet very powerful steam. The steam generator is fitted with silencing steam filters to reduce the noise of the steam and a sound-absorbing platform to reduce the noise of the pump in the base.

OptimalTEMP technology



Now you can iron everything from jeans to silk with no temperature setting required. Guaranteed no burn on all ironable fabrics. Revolutionary technology with both the Advanced Smart Control Processor, which precisely controls the soleplate temperature so that you don't need to, and the powerful cyclonic steam chamber, which delivers consistent, powerful steam, making ironing easier and faster.

Easy De-calc



Ultra-long-lasting steam performance: Philips' exclusive Easy De-Calc function provides the ideal way to get rid of limescale and extend the lifetime of your steam generator iron. Your iron will remind you to de-calc with light and sound. When your appliance is cold, simply open the Easy De-Calc knob and collect the dirty water and limescale in a cup.

New SteamGlide soleplate



The new SteamGlide soleplate is the best Philips soleplate. Is extremely scratch resistant, glides excellently and is easy to clean.

Safety carry lock



Your steam generator iron comes with a safety carry lock. You can lock your iron safely on the

base, making it safer and reducing the risk of people touching the hot soleplate. You can also carry the steam generator easily.

Safe rest



The innovative Philips OptimalTEMP technology guarantees no burns on all ironable fabrics. During ironing, there is no need to put your iron back on the base station; just leave the hot iron soleplate directly on the garments or cotton ironing board cover without an additional resting accessory. It will not damage any of your ironable garments, or the board. This makes your ironing easier, with less wrist effort.

Automatic shut-off



The safety auto off function automatically switches off the appliance if it has not been used for a few minutes, also saving energy.

Steam generator iron
Max 6.5-bar pressure Up to 350 g steam boost, Carry lock, 1.5 l detachable water tank

GC9550/02

Specifications

Calc management

- Calc clean solution: Easy De-calc
- Suitable for tap water

Technical specifications

- Weight of iron + base: 5.1 kg
- Weight of iron: 1.2 kg
- Voltage: 220 - 240 V
- Product dimensions: 28.3 x 26.3 x 42.4 cm
- Packaging dimensions: 33.5 x 30.5 x 49.1 cm

Easy to use

- Water tank capacity: 1500 ml
- Refill any time
- Heat-up time: 2 min
- Filling and emptying water: Detachable water tank, Extra-large filling hole
- Safe for all fabrics: Even for delicates such as silks
- Safety auto off
- Storage solution: Carry lock

- Cord freedom (swivel): 180 degree cord freedom
- Cord storage: Cord storage compartment
- Power cord length: 1.8 m
- Hose length: 1.7 m
- Hose storage: Hose storage compartment

Sustainability

- Energy saving mode

Fast and powerful crease removal

- Soleplate: SteamGlide
- OptimalTEMP technology
- Power: 2400 W
- Safe rest
- Pressure: Up to 6.5
- Steam boost: 350 g
- Vertical steaming
- Variable steam settings
- Steam output control
- Steam tip



Issue date 2023-08-22

Version: 1.0.2

EAN: 87 10103 63162 0

© 2023 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com