

LIPS
Saeco



SYNTIA

Philips Saeco Syntia
Super-automatic
espresso machine

- Classic Milk Frother
- Stainless steel



HD8836/19

Live the pleasure of Italian espresso at home

compact and stylish bean-to-cup system

the perfect synthesis between compactness, performance, design and premium materials

Authentic Italian coffee perfection

- Delicious milk froth thanks to the classic milk frother
- Coffee without burnt taste thanks to 100% ceramic grinders
- Coffee without the wait thanks to the quick-heat boiler

Easy to clean and maintain

- Always a clean machine thanks to auto-clean and descaling
- Easy cleaning thanks to removable brewing group


Easy to clean and maintain

- Easy cleaning thanks to dishwasher-safe parts

Set the beverages to suit your taste

- Save your favourite coffee settings
- Avoid heat loss and fit every cup with our adjustable spout
- Play with the coffee's richness with our adjustable grinders

 **Saeco**



Highlights

100% ceramic grinders



This espresso machine is equipped with 100% ceramic grinders. Saeco uses ceramic grinders because of their consistent grind without overheating the coffee bean, for an impeccable espresso. Ceramic also ensures long-lasting performance and totally silent operation.

Quick-heat boiler



The Saeco quick-heat boiler technology ensures your machine is always ready. Now you won't have to wait between brewing each espresso, but can prepare coffee after coffee.

Classic milk frother



This Saeco espresso machine comes with the classic milk frother, which baristas call

"Pannarello". It dispenses steam and needs to be immersed in the milk to prepare gorgeous milk foam. Unleash your inner barista by preparing your delicious milk specialties the traditional way!

Saves your coffee settings



You will always get a perfect cup of espresso brewed just for you, according to your personal preference, thanks to our innovative memo function for adjusting the coffee length, strength and temperature. Enjoy a superb coffee drink in your favourite cup at the touch of a button.

Adjustable spout



The adjustable spout on our espresso machines will fit every cup and thus prevent the coffee splashing or cooling down while being poured into your cup. This way your espresso is always served at the right temperature, while the machine is kept clean.

Dishwasher-safe parts



For your convenience, you can put the Saeco's drip tray and milk frother or milk carafe in the dishwasher. This will save time and ensure a hygienic clean.

5-step adjustable grinders



Different coffee blends require different levels of granularity for the full flavour to unfold. The grind granularity of this espresso machine can be adjusted in 5 settings, from the finest grind, for a full-bodied espresso, to the coarsest, for a lighter café crème.

Specifications

Easy to use

- Usage: Adjustable coffee dispenser, Bypass for grinded coffee, Frontal access to all functions, Rapid steam, Removable brewing group, Removable water tank
- Cleaning and maintenance: Automatic coffee circuit rinse

Weight and dimensions

- Product dimensions (L x D x H): 256 x 315 x 415 mm
- Product weight: 9 kg
- Coffee bean capacity: 250 g
- Waste container capacity: 8 serv
- Maximum cup height: 110 mm
- Water tank capacity: 1.2 L

Technical specifications

- Cord length: 80 cm
- Boiler material: Inox
- Voltage: 230 V
- Supported coffee types: Whole coffee beans, Ground coffee

- Power: 1400 W
- Frequency: 50 Hz
- Country of origin: Designed in Italy, Made in Italy
- Water pressure in pump: 15 bar (perfect espresso)
- Number of water boilers: 1 boiler
- Removable brewing group

Perfect Espresso

- Espresso technology: Saeco adapting system, Aroma-system: pre-brewing

Multi-Beverage

- Milk Variations: Pannarello: milk frothing

Service

- 2-year worldwide guarantee

Technical data

- Power: 1400 W
- Voltage: 230 V
- Pump Pressure: 15 bar
- Frequency: 50 Hz



Issue date 2022-06-21

Version: 1.1.1

© 2022 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com