



Philips Saeco Intelia
Super-automatic
espresso machine

- Brews 7 coffee varieties
- Integrated milk jug & frother
- Stainless steel

HD8753/87

One touch Espresso and Cappuccino

With Saeco's latest Latte Perfetto technology

Only the Saeco Intelia super-automatic espresso machine offers you the perfect Espresso experience, easy to use, easy to customize, easy to clean. Prepare perfect Cappuccino or Espresso with just a touch of a button.

Authentic Italian coffee perfection

- Coffee without burnt taste thanks to 100% ceramic grinders
- Coffee without waiting thanks to the quick heat boiler
- Perfect froth thanks to the dual chamber milk carafe

Ease of cleaning and maintaining

- Always a clean machine thanks to auto-clean and descaling
- Easy cleaning thanks to removable brewing group


Ease of cleaning and maintaining

- Easy cleaning thanks to dishwasher-safe parts
- Cutting-edge design with stainless steel finish

Set the beverages to suit your taste

- Save your favorite coffee settings
- Avoid heat loss and fit every cup with our adjustable spout
- Play with the coffee's richness with our adjustable grinders

 **Saeco**



Highlights

Stainless steel



The cutting-edge design of your Saeco espresso machine is rounded off by the stainless steel finish. The stainless steel provides a high quality look and will be a highlight on your kitchen counter tops. It also gives greater resistance for a long-lasting performance.

100% ceramic grinders



This espresso machine is equipped 100% ceramic grinders. Saeco uses ceramic grinders because of their consistent grind without overheating the coffee bean for an impeccable espresso. Ceramic also ensures long-lasting performance and a totally silent operation.

Quick heat boiler



The Saeco quick heat boiler technology ensures your machine is always ready. Now you won't have to wait between brewing each espresso, but can prepare coffee after coffee.

Dual chamber milk carafe



Enjoy your milk specialties fully automated with the patented milk carafe with dual chamber technology. Simply pour milk into the carafe, plug it into the machine and select your coffee drink. With the dual chamber technology you will always enjoy professional coffee drinks with dense, long-lasting milk froth at the ideal temperature from a constant splash-free flow of milk.

Saves your coffee settings



You will always get a perfect cup of espresso brewed just for you, according to your personal preference, thanks to our innovative memo function to adjust the coffee length, strength and temperature. Enjoy a superb coffee drink in your favorite cup with just the press of a button.

Adjustable spout



The adjustable spout on our espresso machines will fit every cup and thus prevents the coffee splashing or cooling down while pouring in your cup. This way your espresso is always served at the right temperature while maintaining a clean machine.

Specifications

Features

- Brita Filter compatible: Optionable
- Simultaneous brewing
- Hot water wand

Perfect Espresso

- Espresso technology: Saeco adapting system, Aroma-system: pre-brewing

Energy saving

- Energy saving: Automatic stand-by

Technical specifications

- Supported coffee types: Ground coffee, Whole coffee beans
- Cord length: 80 cm
- Boiler material: Stainless steel (Inox)
- Power: 1900 W
- Country of origin: Designed in Italy, Made in Europe
- Water pressure in pump: 15 bar (perfect espresso)
- Number of water boilers: 1 boiler
- Removable brewing group

Design

- Colour: Black and steel
- Materials and finishing: Frontal Stainless steel, stainless steel grid, stainless steel cup holder

Weight and dimensions

- Coffee bean capacity: 300 g
- Product dimensions (L x D x H): 256 x 340 x 444 mm
- Product weight: 8.9 kg
- Waste container capacity: 10 servings
- Maximum cup height: 130 mm
- Water tank capacity: 1.5 L
- Milk carafe capacity: 0.5 L

Easy to use

- Cleaning and maintenance: Automatic coffee circuit rinse, Descaling cycle
- Usage: Adjustable coffee dispenser, Cup holding surface, Rapid steam, Removable brewing group, Normal / long espresso option

Service

- 1-year guarantee



Issue date 2023-08-22

Version: 1.1.1

UPC: 0 75020 02581 4

© 2023 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com