

Philips Viva Collection
Airfryer

TurboStar

Low fat fryer
White, 1425W, 0.8kg

HD9621/06



Great tasting fries with up to 80% less fat*

Thanks to patented TurboStar technology

With Philips unique TurboStar technology you can fry food using minimal oil and prepare delicious and evenly cooked dishes. There's no need for preheating and with the new compact design you can still cook large amount of food.

Fast, easy and time efficient

- Detachable parts- dishwasher safe
- Easy clean in 90 secs- QuickClean basket with non-stick mesh
- Tasty food in less time: no pre-heating required
- Fry, bake, grill and roast your favorite foods at home

Healthy and tasty results every time

- Delicious dishes:tender on the inside, crispy on the outside
- Over 200 recipes in app and free recipe book included
- Up to 50% more homogenous end results-TurboStar technology*
- Unique TurboStar technology for healthier frying

Thoughtfully designed

- Large 0.8 kg capacity, 20% compacter*
- Universal removable handle - easily exchange accessories

PHILIPS

Highlights

Crispy and tender results



Thanks to Philips TurboStar technology, all food is exposed to this constant, circulating heat and is cooked through simultaneously. The result is evenly fried food – with no turning needed - even when food is piled up. In addition to the heated air flow, powerful direct heat from above quickly crisps the food for delicious, golden-brown results. “Crispy on the outside, tender on the inside”

QuickClean basket



With Philips' Airfryer QuickClean basket which includes a removable non-stick mesh, cleaning becomes easier and faster. The removable nonstick coated drawer and the food basket are dishwasher safe for easy cleaning. Philips

Airfryer with TurboStar technology saves you and your home from the smell of fried oil compared to a regular fryer.

Small in size, big in capacity



The new Airfryer has been designed with compactness in mind (20% smaller) while still enabling to cook large amount of food (800 gr). With its reduced size it blends in perfectly onto the kitchen counter-top and serves delicious meals for the whole family. Its thoughtful size enables every day usage and a world of possibilities.

Universal removable handle



Philips' new universal removable handle helps you to mix and match the right cooking

accessory and achieve the best results for your key dishes- every day. Additionally it allows for compacter storage after use.

50% more homogenous results



The innovative Philips TurboStar rapid air technology swirls the hot air rapidly through the whole basket. This results in more homogenous heat distribution and therefore 50% more evenly fried food*. There is no need for turning- even when food is piled up. In addition, powerful direct heat from above quickly crisps the food.

Healthier frying



The unique Philips TurboStar generates fast superheated air to fry your food with little to no added oil. Philips Airfryer also creates less smell than conventional fryers, it is easy to clean, safe and economical for your daily use!

Specifications

Technical specifications

- Voltage: 220 V
- Cord length: 0.8 m
- Power: 1425 W

Accessories

- Included: Recipe booklet

Design

- Color: White & grey

Technical specifications

- Capacity basket: 0.8 kg

Weight and dimensions

- Dimensions of product (LxWxH): 365x266x292 mm
- Weight of product: 5,3 kg

Sustainability

- Packaging: > 90% recycled materials
- User manual: 100% recycled paper

General specifications

- Product features: Automatic shut-off, Cool wall exterior, Cord storage, Dishwasher safe, On/off switch, Ready signal, Temperature control, Power-on light, Quickclean, Recipe book & App, Non-slip feet
- Technology: TurboStar technology
- Time control: Up to 30 minutes

Finishing

- Material of main body: Plastic

Service

- 1-year guarantee



Issue date 2022-06-19

Version: 2.2.1

EAN: 00 07502 00785 82

© 2022 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com

* Compared to fresh fries prepared in a conventional Philips fryer.
* versus Philips Viva Collection Airfryer, total capacity can fit 800 gr of fries
* measured vs Airfryer without TurboStar with frozen fries, evaluated on browning and doneness