



Philips Saeco Xsmall
Super-automatic
espresso machine

- Brews 2 coffee varieties
- Classic Milk Frother
- Silver
- 5 step adjustable grinder

HD8745/47

Taste the aroma of your favorite coffee beans

one touch bean to cup espresso

Whatever coffee you wish to try next, the Saeco Xsmall will grind the beans fresh on the spot at the touch of a button. It comes equipped with a steam pipe to add a touch of milk froth pleasure to all your fresh coffee drinks.

High comfort is part of the experience

- Auto-cleaning cycle removes any hassle

Advanced technology designed for coffee perfection

- Velvety milk foam with the Classic Milk Frother


High comfort is part of the experience

- The fully removable brewing group can be cleaned in no time

Advanced technology designed for coffee perfection

- 20,000 cups of finest coffee with durable ceramic grinders
- Fine-tune the coffee's richness with 5 grinder settings

 **Saeco**



Highlights

5-steps adjustable grinders



When it comes to the fineness of the grind, this machine never fails to satisfy. Different coffee blends require different levels of granularity for the full flavor to unfold. So the grind granularity of this machine has five adjustable settings - from the finest grind for a full-bodied espresso, to the coarsest for a lighter coffee.

100% Ceramic grinders



Our grinders are made of high-tech ceramic: exceptionally hard and precise. Fresh beans are gently ground, without risk of overheating:

extracting all the best flavors and aroma, delivering a superior coffee taste for at least 20,000 cups.

Removable brewing group



Efficiency and ease of use were key inspirations when Saeco invented the first brewing group 30 years ago. And to this day, it still proves to be an inspired, resolute piece of technology. As always, it's so simple to clean – just remove it and wash it under the tap for a few seconds, then re-insert it just as easily.

Auto-cleaning



The automatic cleaning cycle makes it easy to look after, and it increases the machine's longevity – giving you more time to enjoy your coffee instead of cleaning up.

Classic Milk Frother



The Classic Milk Frother is for those who love to assume the role of master craftsman, and it's just easy. Within seconds you can create a rich, silky layer of foam - the crowning glory of your coffee.

Specifications

Country of origin

- Made in: Europe

Technical specifications

- Voltage: 120 V
- Capacity bean container: 180 g
- Cord length: 0.8 m
- Frequency: 60 Hz
- Capacity water tank: 1 L
- Capacity waste container: 8 servings
- Pump pressure: 15 bar
- Max. cup height: 95 mm
- Water boilers: 1
- Pump pressure: 15 bar

Design

- Color: Black, Silver

Weight and dimensions

- Dimensions of product (WxDxH): 295 x 420 x 325 mm
- Weight of product: 8.0 kg

General specifications

- Suitable for: Whole coffee beans, ground coffee powder

- Cups at the same time: 2
- Ease of cleaning & maintenance: Removable brewing group, Automatic rinse cycle, Dishwasher-safe parts, Automatic de-scaling cycle
- Ease of use and comfort: Removable water tank, Removable drip-tray
- Special functions: Manual milk frother Pannarello, Ceramic grinder, Pre-brewing, Hot water option, Steam option
- Type of boiler: Stainless steel boiler
- Coffee drinks: Espresso, Cappuccino, hot water, Café Crème, frothed milk, Espresso Macchiato, Latte Macchiato

Finishing

- Material of main body: Plastic
- Material boiler: Stainless steel (Inox)
- Material drip tray: Stainless steel
- Material water tank: Plastic
- Material panarello: Plastic

Service

- 1-year guarantee

Sustainability

- Power consumption brewing: 1400 W



Issue date 2023-08-22

Version: 1.1.1

UPC: 0 75020 02027 7

© 2023 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com