



**Saeco Moltio  
Super-automatic  
espresso machine**

- Brews 7 coffee varieties
- Automatic Milk Frother
- Black
- 5-step adjustable grinder



**HD8768/08**

## Every moment deserves its coffee flavour

### Changing beans is now one click away

The Moltio espresso machine, a unique masterpiece crafted to offer a tailored taste experience. Thanks to our exclusive bean switcher, preparing the right coffee that always matches your mood and the occasion will be as easy as a click

#### **Authentic Italian coffee perfection**

- Coffee without burnt taste thanks to 100% ceramic grinders
- Coffee without the wait thanks to the quick-heat boiler

#### **Authentic Italian coffee perfection**

- Delicious froth thanks to a patented automatic milk frother

#### **Easy to clean and maintain**

- Always a clean machine thanks to auto-clean and descaling
- Easy cleaning thanks to removable brewing group

#### **Easy to clean and maintain**

- Easy cleaning thanks to dishwasher-safe parts

#### **Set the beverages to suit your taste**

- Experiment with flavours with the coffee bean switcher

 **Saeco**

# Highlights

## 100% ceramic grinders



This espresso machine is equipped with 100% ceramic grinders. Saeco uses ceramic grinders because of their consistent grind without overheating the coffee bean, for an impeccable espresso. Ceramic also ensures long-lasting performance and totally silent operation.

## Quick-heat boiler



The Saeco quick-heat boiler technology ensures your machine is always ready. Now you won't have to wait between brewing each espresso, but can prepare coffee after coffee.

## Coffee bean switcher



With the Saeco Moltio espresso machines you can now change beans with just one click

thanks to the patented exchangeable bean container. Enjoy the convenience of quickly changing the bean blend and find the perfect fit for every taste preference and moment of the day.

## Automatic milk frother



Preparing a tasty cappuccino is easy with this Saeco espresso machine thanks to the new patented automatic milk frother with its cyclonic chamber. The milk frother, which baristas also call "cappuccinatore", will draw milk directly from a milk carton or jug and froth it automatically, dispensing it directly into your cup. And thanks to the exclusive cyclonic chamber, a constant flow of milk without any splashing is guaranteed.

## Saves your coffee settings



You will always get a perfect cup of espresso brewed just for you, according to your personal preference, thanks to our innovative memo function for adjusting the coffee length, strength and temperature. Enjoy a superb coffee drink in your favourite cup at the touch of a button.

## Dishwasher-safe parts



For your convenience, you can put the Saeco's drip tray and milk frother or milk carafe in the dishwasher. This will save time and ensure a hygienic clean.

## 5-step adjustable grinders



Different coffee blends require different levels of granularity for the full flavour to unfold. The grind granularity of this espresso machine can be adjusted in 5 settings, from the finest grind, for a full-bodied espresso, to the coarsest, for a lighter café crème.

# Specifications

## Easy to use

- Usage: Adjustable coffee dispenser, Cup-holding surface, Rapid steam, Removable brewing group, Normal/long espresso option
- Cleaning and maintenance: Automatic coffee circuit rinse, Descaling cycle

## Weight and dimensions

- Product dimensions (L x D x H): 256 x 470 x 350 mm
- Product weight: 8.5 kg
- Coffee bean capacity: 290 g
- Waste container capacity: 15 serv
- Maximum cup height: 142 mm
- Water tank capacity: 1.9 L

## Technical specifications

- Cord length: 80 cm
- Supported coffee types: Ground coffee, Whole coffee beans
- Voltage: 230 V
- Power: 1850 W
- Country of origin: Designed in Italy, Made in Europe

- Frequency: 50 Hz
- Water pressure in pump: 15 bar (perfect espresso)
- Number of water boilers: 1 boiler
- Removable brewing group

## Features

- Brita Filter compatible: Optional
- Cappuccinatore
- Hot water/Steam Nozzle
- Simultaneous brewing

## Design

- Colour: Black
- Materials and finishing: Plastic

## Perfect Espresso

- Espresso technology: Saeco adapting system, Aroma-system: pre-brewing

## Service

- 2-year worldwide guarantee

## Sustainability

- Automatic Standby Option