

LIPS
Saeco

SYNTIA

Philips Saeco Syntia
Super-automatic
espresso machine

• Stainless steel



HD8837/02

Live the pleasure of Italian espresso at home

Compact and stylish bean-to-cup system

Syntia is the perfect synthesis of compactness, performance, design and high end materials—everything for your Italian espresso enjoyment at a single touch

Grind your favourite coffee beans

- Play with the coffee's richness with our adjustable grinders
- Adjust coffee length, temperature, strength

Enjoy an Italian lifestyle at home

- Compact and stylish
- One touch espresso and long coffee

Easy to clean and maintain

- Always a clean machine thanks to auto-clean and descaling
- Easy cleaning thanks to removable brewing group

Easy to use

- Ergonomic in day to day operation

Easy to use

- Self-explanatory, colour-coded user interface

 **Saeco**

Highlights

Espresso and long coffee



Whether you want to enjoy an espresso or a long coffee, your favourites are accessible at the touch of a button

5-step adjustable grinders



Different coffee blends require different levels of granularity for the full flavour to unfold. The grind granularity of this espresso machine can be adjusted in 5 settings, from the finest grind, for a full-bodied espresso, to the coarsest, for a lighter café crème.

Auto-cleaning and descaling



Saeco designed this espresso machine to automatically clean its coffee circuit with water when starting up or switching off to deliver a great, fresh taste with each cup of coffee.

Regular descaling prolongs your espresso machine's life. This machine will not only prompt when descaling is needed, the automated descaling process will start and guide you with clear on-screen messages when you have to intervene. Descaling has never been so easy!

Removable brewing group



The brewing group, a Saeco invention, is the heart of our espresso machines, ensuring automation. The brewing group is, depending on the model, easily accessible from the front or side. It can be removed effortlessly for easy cleaning by rinsing under the tap, ensuring maximum hygiene.

Colour coded user interface

Enjoy direct and clear interaction thanks to the self-explanatory icons display. For maximum convenience the icons are coloured according to the traffic light colours: Red requires action, Yellow means the coffee machine is "busy" (e.g. heating up) and Green is ready to use.

Coffee customisation



Saeco machines offer you the possibility of customising your coffee exactly the way you

like it - from the most intense espresso to a mild cup of long coffee.

Compact and stylish



Compact and stylish, the Syntia coffee machine is designed to delight both your palate and your eyes - the perfect fit for a modern kitchen.

Ergonomic day to day



Saeco is a synonym for convenience: refilling beans or water, emptying the coffee-dump box or the drip tray, all compartments of the full automatic coffee machine are directly accessible.

Specifications

Easy to use

- Usage: Adjustable coffee dispenser, Bypass for grinded coffee, Frontal access to all functions, Rapid steam, Removable brewing group, Removable water tank
- Cleaning and maintenance: Automatic coffee circuit rinse

Weight and dimensions

- Product dimensions (L x D x H): 256 x 315 x 415 mm
- Coffee bean capacity: 250 g
- Waste container capacity: 8 serv
- Maximum cup height: 110 mm
- Water tank capacity: 1.2 L

Technical specifications

- Boiler material: Stainless steel (Inox)
- Supported coffee types: Ground coffee, Whole

coffee beans

- Number of water boilers: 1 boiler

Perfect Espresso

- Espresso technology: Saeco adapting system, Aroma-system: pre-brewing

Multi-Beverage

- Milk Variations: Pannarello: milk frothing

Service

- 2-year worldwide guarantee

Technical data

- Power: 1400 W
- Voltage: 230 V
- Pump Pressure: 15 bar
- Frequency: 50 Hz



Issue date 2022-07-06

Version: 1.1.1

© 2022 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com