



**Saeco Energica
Super-automatic
espresso machine**

- Integrated milk jug & frother
- Stainless steel

HD8852/47

Perfect, hot, clean.

That's the premium milk froth experience

Only Saeco Energica espresso machine delivers the perfect espresso and milk experience, always ready, equipped with integrated Milk Frother.

Authentic Italian coffee perfection

- Coffee without burnt taste thanks to 100% ceramic grinders
- Perfect milk froth thanks to the integrated milk carafe
- Milk specialties without the wait thanks to a double boiler

Ease of cleaning and maintaining

- Always a clean machine thanks to auto-clean and descaling
- Easy cleaning thanks to removable brewing group


Ease of cleaning and maintaining

- Hygienic milk frothing thanks to automated dual cleaning
- Cutting-edge design with stainless steel finish

Set the beverages to suit your taste

- Play with the coffee's richness with our adjustable grinders
- Boost coffee crema and body

 **Saeco**



Highlights

Stainless steel



The cutting-edge design of your Saeco espresso machine is rounded off by the stainless steel finish. The stainless steel provides a high quality look and will be a highlight on your kitchen counter tops. It also gives greater resistance for a long-lasting performance.

8 step adjustable grinders



Different coffee blends require different levels of granularity for the full flavor to unfold. The grind granularity of this espresso machine can be adjusted in 8 settings, from the finest grind, for a full bodied espresso, to the coarsest, for a lighter coffee.

Removable brewing group



The brewing group, a Saeco invention, is the heart of our espresso machines, ensuring automation. The brewing group is, depending on the model, easily accessible from the front or side. It can be removed effortlessly for easily cleaning by rinsing under the tap ensuring maximum hygiene.

100% ceramic grinders



This espresso machine is equipped 100% ceramic grinders. Saeco uses ceramic grinders because of their consistent grind without overheating the coffee bean for an impeccable espresso. Ceramic also ensures long-lasting performance and a totally silent operation.

Saves your coffee settings



You will always get a perfect cup of espresso brewed just for you, according to your personal preference, thanks to our innovative memo function to adjust the coffee length, strength and temperature. Enjoy a superb coffee drink in your favorite cup with just the press of a button.

Automatic dual cleaning carafe



This Saeco espresso machine comes with a fully automated dual clean function for its milk carafe. The dual cleaning uses two independent steam cycles to swiftly rinse your milk carafe after each coffee drink you prepare, for a fresh milk drink everytime. Hygienic milk frothing was never this easy.

Specifications

Perfect Espresso

- Espresso technology: Saeco adapting system, Aroma-system: pre-brewing

Multi-Beverage

- Milk Variations: Integrated auto milk function, Milk quantity selector, Removable milk carafe

Technical specifications

- Voltage: 120 V
- Cord length: 80 cm
- Supported coffee types: Ground coffee, Whole coffee beans
- Boiler material: Stainless steel (Inox)
- Power: 1400 W
- Country of origin: Designed in Italy, Made in Italy
- Frequency: 60 Hz
- Water pressure in pump: 15 bar (perfect espresso)
- Number of water boilers: 1 boiler
- Removable brewing group

Design

- Colour: Stainless steel
- Materials and finishing: Stainless steel / ABS Plastic

Weight and dimensions

- Coffee bean capacity: 300 g
- Product dimensions (L x D x H): 245 x 360 x 420 mm
- Product weight: 13.4 kg
- Waste container capacity: 11 servings
- Maximum cup height: 150 mm
- Water tank capacity: 1.5 L
- Milk carafe capacity: 0.5 L

Easy to use

- Usage: Adjustable coffee dispenser, Bypass for grinded coffee, Frontal access to all function, Instant steam (2 boilers), Removable brewing group, Removable watertank
- Cleaning and maintenance: Automatic coffee circuit rinse, Automatic milk circuit rinse, Descaling cycle

Service

- 1-year guarantee



Issue date 2023-08-22

Version: 1.1.1

UPC: 0 75020 03328 4

© 2023 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com