



Philips Saeco Xelsis
Super-automatic
espresso machine

- Integrated milk jug and frother
- Black Stainless Steel



HD8942/11

Multi-beverage, multi-user

with fully automated dual cleaning milk carafe

With the Saeco Xelsis coffee machine, each and every family member can enjoy his or her favourite coffee specialty. Up to 9 coffee specialties can be fully personalised.

Authentic Italian coffee perfection

- Coffee without burnt taste thanks to 100% ceramic grinders
- Perfect milk froth thanks to the integrated milk carafe
- Milk specialties without the wait thanks to a double boiler

Easy to clean and maintain

- Always a clean machine thanks to auto-clean and descaling
- Easy cleaning thanks to removable brewing group


Easy to clean and maintain

- Hygienic milk frothing thanks to automated dual cleaning

Set the beverages to suit your taste

- Play with the coffee's richness with our adjustable grinders
- Personalise your coffee in 6 user profiles
- Boost coffee crema and body

 **Saeco**



Highlights

100% ceramic grinders



This espresso machine is equipped with 100% ceramic grinders. Saeco uses ceramic grinders because of their consistent grind without overheating the coffee bean, for an impeccable espresso. Ceramic also ensures long-lasting performance and totally silent operation.

8-step adjustable grinders



Different coffee blends require different levels of granularity for the full flavour to unfold. The grind granularity of this espresso machine can be adjusted in 8 settings, from the finest grind, for a full-bodied espresso, to the coarsest, for a lighter café crème.

6 user profiles



This Saeco espresso machine comes with 6 customisable profiles that memorise your

personal preference for different coffee drinks. This makes it very easy to get a perfect tailor-made cup of coffee, even if you are not the only one using the machine.

Removable brewing group



The brewing group, a Saeco invention, is the heart of our espresso machines, ensuring automation. The brewing group is, depending on the model, easily accessible from the front or side. It can be removed effortlessly for easy cleaning by rinsing under the tap, ensuring maximum hygiene.

Automatic dual-cleaning carafe



This Saeco espresso machine comes with a fully automated dual-clean function for its milk carafe. The dual cleaning uses two independent steam cycles to swiftly rinse your milk carafe after each coffee drink you prepare, for a fresh milk drink every time. Hygienic milk frothing has never been this easy.

Auto-cleaning and descaling



Saeco designed this espresso machine to automatically clean its coffee circuit with water when starting up or switching off to deliver a great, fresh taste with each cup of coffee. Regular descaling prolongs your espresso machine's life. This machine will not only prompt when descaling is needed, the automated descaling process will start and guide you with clear on-screen messages when you have to intervene. Descaling has never been so easy!

Professional double boiler



With 2 separate heating systems to cater for both the optimal coffee temperature and the milk frothing temperature, this Saeco fully automatic espresso machine guarantees professional performance and speed every time. You are able to prepare as many latte macchiatos and cappuccinos as you wish, one after the other and each just as good as the previous one, without waiting.

Specifications

Easy to use

- Usage: Adjustable coffee dispenser, Bypass for grinded coffee, Cup-holding surface, Frontal access to all functions, Instant steam (2 boilers), Removable brewing group, Removable water tank
- Cleaning and maintenance: Automatic coffee circuit rinse, Automatic milk circuit rinse, Descaling cycle

Weight and dimensions

- Coffee bean capacity: 350 g
- Product weight: 16.1 kg
- Product dimensions (L x D x H): 280 x 370 x 420 mm
- Waste container capacity: 14 serv
- Weight: 13,9 kg
- Maximum cup height: 150 mm
- Milk carafe capacity: 0.5 L
- Water tank capacity: 1.6 L

Technical specifications

- Cord length: 80 cm
- Boiler material: Inox
- Voltage: 230 V
- Supported coffee types: Ground coffee, Whole coffee beans
- Power: 1500 W

- Frequency: 50 Hz
- Country of origin: Designed in Italy, Made in Italy
- Water pressure in pump: 15 bar (perfect espresso)
- Number of water boilers: 2 boilers (instant steam)
- Removable brewing group

Perfect Espresso

- Espresso technology: Saeco adapting system, Aroma-system: pre-brewing, SBS: creme adaptor

Multi-Beverage

- Milk Variations: Frothing degree adaptor, Integrated auto milk function, Milk quantity selector, Removable milk carafe

Service

- 2-year worldwide guarantee

Technical data

- Power: 1500 W
- Voltage: 230 V
- Pump Pressure: 15 bar
- Frequency: 50 Hz

Sustainability

- Automatic Standby Option



Issue date 2022-06-23

Version: 1.1.1

© 2022 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com