

Philips PowerPro Active
Bagless vacuum cleaner

2000W

PowerCyclone 4
HEPA 10 washable filter
Animal

FC8633/61



Always the highest suction power*

With PowerCyclone 4 Technology

The new Philips PowerPro Active vacuum cleaner delivers outstanding cleaning results thanks to the PowerCyclone 4 technology. The advance dust container is easy to empty and helps avoiding dust clouds.

Easy to clean

- Advanced dust container design for easy to emptying

Clean air in your home

- The EPA filter catches microscopic vermin causing allergy

Outstanding results on carpets and furniture

- Mini Turbo brush for easy (pet) hair and fluff removal

Ergonomic grip for far reach

- Reach all corners thanks to the extra long ergonomic grip

Powerful cleaning performance

- PowerCyclone 4 technology separates dust and air in one go
- 2000 Watt motor for high performance

PHILIPS

Highlights

Easy to empty dust container



The dust container is perfectly designed to dispose dust without creating a dust cloud. Thanks to its unique shape and smooth surface, dust is collected at one side of the container and evenly glides into the dust bin.

PowerCyclone 4 Technology



PowerCyclone 4 technology maximizes airflow and performance by separating dirt from air in one go. It delivers remarkable cleaning results through highly efficient steps: 1) Air enters fast into the PowerCyclone thanks to the straight and smooth air inlet. 2) The curved airpass quickly accelerates the air upwards in the cyclonic chamber to separate the dust from the air.

EPA filter system



The pleated EPA filter has a large filter surface and good filtration performance. In combination with the

cyclonic airflow, this prevents it from clogging fast and gives you better and longer-lasting filtration results.

2000 Watt motor



The 2000 Watt motor generates max. 370 Watt suction power for high performance.

Extra long ergonomic grip



This ergonomically shaped grip is convenient in use. Its extra long design gives you farther reach, so you can easily clean hard to reach places.

Mini Turbo brush



The Mini Turbo Brush quickly removes (animal) hairs, fluff, and dust from couches, cushions, and other fabrics. This brush is ideal for pet owners.

Specifications

Design

- Color: Merlin blue metallic

Performance

- Input power (IEC): 1800 W
- Input power (max): 2000 W
- Noise level (Lc IEC): 80 dB
- Suction power (max): 370 W
- Vacuum (max): 33 kPa
- Airflow (max): 37 l/s

Usability

- Tube coupling: Conical
- Action radius: 9 m
- Cord length: 6 m
- Carrying handle: Top and front
- Tube type: Aluminum telescopic tube
- Power control: Electronic on appliance
- Wheel type: Rubber

Nozzles and accessories

- Accessories included: Crevice tool, Small nozzle
- Standard nozzle: Multi-purpose nozzle
- Accessory storage: On tubeclip
- Additional nozzle: Mini turbo brush

Weight and dimensions

- Dimensions of product (LxWxH): 473x304x301 mm
- Weight of product: 6 kg

Sustainability

- Packaging: > 90% recycled materials
- User manual: 100% recycled paper

Filtration

- Dust capacity: 1.7 L
- Exhaust filter: Microfilter
- Motor filter: EPA 10 washable filter



Issue date 2022-05-03

Version: 1.1.1

EAN: 08 71010 36529 77

© 2022 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com

* Suction power results compared to Philips PowerPro Compact FC8470, tested internally January 2013.