



Philips SalonPro AC
professional
Hairdryer

HP4892



SalonPro AC Professional

The dryer that hairdressers would use at home

The SalonPro offers power, protection and professional styling results. It's the dryer hairdressers would be happy to use at home.

Professional results

- Ultra strong airflow from long life professional AC motor
- Diffuser with ceramic tips

Time saving

- Ultra narrow styling nozzle

Prevents damage

- Ceramic element with far-infra red heat prevents over drying
- Ion conditioning for frizz-free, shiny hair

Long lasting styles

- Cool shot sets your style

Easy to use

- 9 heat/speed settings for full flexibility
- LED lights indicate the chosen setting
- Comfortable soft grip handle

PHILIPS
sense and simplicity

Highlights

Professional AC motor



Long life professional AC motor compresses the air for ultra strong airflow and quicker results.

Ultra narrow styling nozzle



Ultra narrow styling nozzle increases the airspeed and facilitates detailed styling.

Ceramic element

The ceramic element prevents over drying. It issues infra red heat, which is a gentle warmth that helps to protect the hair from over drying, without compromising on speed and effectiveness.

Ion conditioning



The ioniser inside the hairdryer creates negative particles, called ions, that neutralise the positive charge hair usually has. This calms the individual strands, brings them back into balance, and removes any static. As a result, hair is smoother and more manageable, and stays perfectly in style.

9 heat/speed settings



9 heat/speeds settings provide maximum flexibility to dry and pre-style your hair the way you want.

Specifications

Technical Specifications

- Wattage: 1350-1800 W
- Frequency: 50/60 Hz
- Voltage: 110-127 V

Weight & dimensions F-box

- Net product dimensions excl. attachments: 284 x 85 x 235 mm
- Weight of net product incl. attachments: 1128 g
- F-box dimensions: 310 (w) x 120 (d) x 240 (h) mm
- Weight F-box [including product]: 1580 g
- Volume F-box: 8928 cm³

Weight & dimensions A-box

- A-box dimensions: 632 x 375 x 257 mm
- Weight A-box [including products]: 10430 g
- Number of F-boxes in A-box: 6
- Volume A-box: 60909 cm³

Pallet

- Pallet dimensions: 1200 x 800 mm
- Pallet quantity: 126 pcs
- Number of layers: 7
- Number of A-boxes per layer: 3

