

**Philips Saeco Xsmall  
Super-automatic  
espresso machine**

- Brews 2 coffee varieties
- Classic Milk Frother
- Black
- 5 step adjustable grinder

**HD8743/15**

## Taste the aroma of your favorite coffee beans

### one touch bean to cup espresso

Whatever coffee you wish to try next, the Saeco Xsmall will grind the beans fresh on the spot at the touch of a button. It comes equipped with a steam pipe to add a touch of milk froth pleasure to all your fresh coffee drinks.

#### **Authentic Italian coffee perfection**

- Coffee without burnt taste thanks to 100% ceramic grinders

#### **Ease of cleaning and maintaining**


- Always a clean machine thanks to automatic circuit cleaning
- Easy cleaning thanks to removable brewing group

#### **Set the beverages to suit your taste**

- Save your favorite coffee length
- Play with the coffee's richness with our adjustable grinders



**Saeco**



# Specifications

## Easy to use

- Usage: Removable brewing group, Removable watertank
- Cleaning and maintenance: Automatic coffee circuit rinse

## Weight and dimensions

- Waste container capacity: 8 servings
- Coffee bean capacity: 180 g
- Product weight: 7.2 kg
- Product dimensions (L x D x H): 420 x 325 x 295 mm
- Maximum cup height: 95 mm
- Water tank capacity: 1 L

## Technical specifications

- Supported coffee types: Whole coffee beans

- Power: 1400 W
- Cord length: 80 cm
- Boiler material: Stainless steel (Inox)
- Voltage: 220 V
- Frequency: 60 Hz
- Country of origin: Designed in Italy, Made in Europe
- Water pressure in pump: 15 bar (perfect espresso)
- Number of water boilers: 1 boiler
- Removable brewing group

## Perfect Espresso

- Espresso technology: Aroma-system: pre-brewing

## Service

- 2-year worldwide guarantee

# Highlights

## Automatic circuit cleaning

Saeco designed this espresso machine to automatically clean its coffee circuit with water upon starting up or switching off of the machine, this delivers a great, fresh taste with each cup of coffee.

## 100% ceramic grinders

This espresso machine is equipped 100% ceramic grinders. Saeco uses ceramic grinders because of their consistent grind without overheating the coffee bean for an impeccable espresso. Ceramic also ensures long-lasting performance and a totally silent operation.

## Saves your coffee length

You will always get a perfect cup of espresso brewed according to your personal preference thanks to our memo function which allows you to adjust the coffee length to suit your taste. Enjoy a superb coffee drink with just the press of a button.

## 5 step adjustable grinders

Different coffee blends require different levels of granularity for the full flavor to unfold. The grind granularity of this espresso machine can be adjusted in 5 settings, from the finest grind, for a full bodied espresso, to the coarsest, for a lighter coffee.

## Removable brewing group

The brewing group, a Saeco invention, is the heart of our espresso machines, ensuring automation. The brewing group is, depending on the model, easily accessible from the front or side. It can be removed effortlessly for easily cleaning by rinsing under the tap ensuring maximum hygiene.

