



Philips Saeco Intelia  
Super-automatic  
espresso machine

- Integrated milk jug & frother
- Stainless steel



HD8753/83

## One touch Espresso and Cappuccino

With Saeco's latest Latte Perfetto technology

Only the Saeco Intelia super-automatic espresso machine offers you the perfect Espresso experience, easy to use, easy to customize, easy to clean. Prepare perfect Cappuccino or Espresso with just a touch of a button.

### Authentic Italian coffee perfection

- Coffee without burnt taste thanks to 100% ceramic grinders
- Coffee without waiting thanks to the quick heat boiler
- Perfect froth thanks to the dual chamber milk carafe


### Ease of cleaning and maintaining

- Always a clean machine thanks to auto-clean and descaling
- Easy cleaning thanks to removable brewing group

### Set the beverages to suit your taste

- Save your favorite coffee settings
- Play with the coffee's richness with our adjustable grinders
- Avoid heat loss and fit every cup with our adjustable spout

 **Saeco**



# Highlights

## 100% ceramic grinders



This espresso machine is equipped 100% ceramic grinders. Saeco uses ceramic grinders because of their consistent grind without overheating the coffee bean for an impeccable espresso. Ceramic also ensures long-lasting performance and a totally silent operation.

## Quick heat boiler



The Saeco quick heat boiler technology ensures your machine is always ready. Now you won't have to wait between brewing each espresso, but can prepare coffee after coffee.

## Dual chamber milk carafe



Enjoy your milk specialties fully automated with the patented milk carafe with dual

chamber technology. Simply pour milk into the carafe, plug it into the machine and select your coffee drink. With the dual chamber technology you will always enjoy professional coffee drinks with dense, long-lasting milk froth at the ideal temperature from a constant splash-free flow of milk.

## Saves your coffee settings



You will always get a perfect cup of espresso brewed just for you, according to your personal preference, thanks to our innovative memo function to adjust the coffee length, strength and temperature. Enjoy a superb coffee drink in your favorite cup with just the press of a button.

## Adjustable spout



The adjustable spout on our espresso machines will fit every cup and thus prevents the coffee splashing or cooling down while pouring in your cup. This way your espresso is always served at the right temperature while maintaining a clean machine.

## 5 step adjustable grinders



Different coffee blends require different levels of granularity for the full flavor to unfold. The grind granularity of this espresso machine can be adjusted in 5 settings, from the finest grind, for a full bodied espresso, to the coarsest, for a lighter coffee.

## Removable brewing group



The brewing group, a Saeco invention, is the heart of our espresso machines, ensuring automation. The brewing group is, depending on the model, easily accessible from the front or side. It can be removed effortlessly for easily cleaning by rinsing under the tap ensuring maximum hygiene.

# Specifications

## Features

- Brita Filter compatible: Optionable
- Simultaneous brewing
- Hot water wand

## Perfect Espresso

- Espresso technology: Saeco adapting system, Aroma-system: pre-brewing

## Logistic data

- Pallet size: 80x204,4x120 cm
- Pallet weight (EU): 162 kg
- Pallet number of pieces: 15

## Water tank

- Water tank capacity: 1,5 L

## Technical data

- Power: 1900 W
- Pump Pressure: 15 bar

## Technical specifications

- Boiler material: Stainless steel (Inox)
- Cord length: 80 cm
- Supported coffee types: Whole coffee beans, Ground coffee
- Power: 1900 W
- Country of origin: Made in Europe, Designed in Italy
- Water pressure in pump: 15 bar (perfect espresso)

- Number of water boilers: 1 boiler
- Removable brewing group

## Design

- Colour: Black and steel
- Materials and finishing: Frontal Stainless steel, stainless steel grid, stainless steel cup holder

## Weight and dimensions

- Product dimensions (L x D x H): 256 x 340 x 444 mm
- Weight: 10,8 kg
- Waste container capacity: 10 servings
- Product weight: 8.9 kg
- Coffee bean capacity: 300 g
- Maximum cup height: 130 mm
- Water tank capacity: 1.5 L
- Milk carafe capacity: 0.5 L

## Easy to use

- Usage: Adjustable coffee dispenser, Cup holding surface, Rapid steam, Removable brewing group, Normal / long espresso option
- Cleaning and maintenance: Automatic coffee circuit rinse, Descaling cycle

## Service

- 1-year guarantee

## Sustainability

- Automatic Stand-by Option



Issue date 2023-08-22

Version: 1.1.1

EAN: 87 10103 57519 1

© 2023 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)