



**Saeco Moltio
Super-automatic
espresso machine**

- Brews 7 coffee varieties
- Integrated milk jug and frother
- Black
- 5-step adjustable grinder



HD8769/08

Every moment deserves its coffee flavour

Changing beans is now one click away

The Moltio espresso machine, a unique masterpiece crafted to offer a tailored taste experience. Thanks to our exclusive bean switcher, preparing the right coffee that always matches your mood and the occasion will be as easy as a click

Authentic Italian coffee perfection

- Coffee without burnt taste thanks to 100% ceramic grinders
- Coffee without the wait thanks to the quick-heat boiler

Authentic Italian coffee perfection

- Perfect froth thanks to the dual-chamber milk carafe

Easy to clean and maintain

- Always a clean machine thanks to auto-clean and descaling
- Easy cleaning thanks to removable brewing group

Easy to clean and maintain

- Easy cleaning thanks to dishwasher-safe parts

Set the beverages to suit your taste

- Experiment with flavours with the coffee bean switcher

 **Saeco**



Highlights

100% ceramic grinders



This espresso machine is equipped with 100% ceramic grinders. Saeco uses ceramic grinders because of their consistent grind without overheating the coffee bean, for an impeccable espresso. Ceramic also ensures long-lasting performance and totally silent operation.

Quick-heat boiler



The Saeco quick-heat boiler technology ensures your machine is always ready. Now you won't have to wait between brewing each espresso, but can prepare coffee after coffee.

Coffee bean switcher



With the Saeco Moltio espresso machines you can now change beans with just one click

thanks to the patented exchangeable bean container. Enjoy the convenience of quickly changing the bean blend and find the perfect fit for every taste preference and moment of the day.

Patented dual-chamber carafe



Enjoy your milk specialties fully automated with the new patented milk carafe with dual-chamber technology. Simply pour milk into the carafe, plug it into the machine and select your coffee drink. With the dual-chamber technology you will always enjoy professional coffee drinks with dense, long-lasting milk froth at the ideal temperature from a constant splash-free flow of milk.

Saves your coffee settings



You will always get a perfect cup of espresso brewed just for you, according to your personal preference, thanks to our innovative memo function for adjusting the coffee length, strength and temperature. Enjoy a superb coffee drink in your favourite cup at the touch of a button.

Dishwasher-safe parts



For your convenience, you can put the Saeco's drip tray and milk frother or milk carafe in the dishwasher. This will save time and ensure a hygienic clean.

5-step adjustable grinders



Different coffee blends require different levels of granularity for the full flavour to unfold. The grind granularity of this espresso machine can be adjusted in 5 settings, from the finest grind, for a full-bodied espresso, to the coarsest, for a lighter café crème.

Specifications

Easy to use

- Usage: Adjustable coffee dispenser, Cup-holding surface, Rapid steam, Removable brewing group, Normal/long espresso option
- Cleaning and maintenance: Automatic coffee circuit rinse, Descaling cycle

Weight and dimensions

- Product weight: 8.5 kg
- Coffee bean capacity: 290 g
- Product dimensions (L x D x H): 256 x 470 x 350 mm
- Waste container capacity: 15 serv
- Maximum cup height: 142 mm
- Milk carafe capacity: 0.5 L
- Water tank capacity: 1.9 L

Technical specifications

- Cord length: 80 cm
- Supported coffee types: Ground coffee, Whole coffee beans
- Voltage: 230 V
- Power: 1850 W
- Frequency: 50 Hz

- Country of origin: Made in Italy, Designed in Italy
- Water pressure in pump: 15 bar (perfect espresso)
- Number of water boilers: 1 boiler
- Removable brewing group

Features

- Brita Filter compatible: Optional
- Cappuccinatore
- Hot water/Steam Nozzle
- Simultaneous brewing

Perfect Espresso

- Espresso technology: Saeco adapting system, Aroma-system: pre-brewing

Design

- Colour: Black
- Materials and finishing: Plastic

Service

- 2-year worldwide guarantee

Sustainability

- Automatic Standby Option