



**Philips Saeco Xsmall
Super-automatic
espresso machine**

- Brews 2 coffee varieties
- Classic Milk Frother
- Black
- 5-step adjustable grinder



HD8743/11

Taste the aroma of your favourite coffee beans

one-touch bean-to-cup espresso

Whatever coffee you wish to try next, the Saeco Xsmall will grind the beans freshly on the spot at the touch of a button. It comes equipped with a steam pipe to add a touch of milk froth pleasure to all your fresh coffee drinks.

Authentic Italian coffee perfection

- Coffee without burnt taste thanks to 100% ceramic grinders


Easy to clean and maintain

- Always a clean machine thanks to automatic circuit cleaning
- Easy cleaning thanks to removable brewing group

Set the beverages to suit your taste

- Save your favourite coffee length
- Play with the coffee's richness with our adjustable grinders

 **Saeco**



Highlights

Automatic circuit cleaning



Saeco designed this espresso machine to automatically clean its coffee circuit with water when the machine is started up or switched off. This delivers a great, fresh taste with each cup of coffee.

100% ceramic grinders



This espresso machine is equipped with 100% ceramic grinders. Saeco uses ceramic grinders because of their consistent grind without overheating the coffee bean, for an impeccable espresso. Ceramic also ensures long-lasting performance and totally silent operation.

Saves your coffee length



You will always get a perfect cup of espresso brewed according to your personal preference thanks to our

memo function, which allows you to adjust the coffee length to suit your taste. Enjoy a superb coffee drink at the touch of a button.

5-step adjustable grinders



Different coffee blends require different levels of granularity for the full flavour to unfold. The grind granularity of this espresso machine can be adjusted in 5 settings, from the finest grind, for a full-bodied espresso, to the coarsest, for a lighter café crème.

Removable brewing group



The brewing group, a Saeco invention, is the heart of our espresso machines, ensuring automation. The brewing group is, depending on the model, easily accessible from the front or side. It can be removed effortlessly for easy cleaning by rinsing under the tap, ensuring maximum hygiene.

Specifications

Country of origin

- Made in: Romania

Weight and dimensions

- Coffee bean capacity: 180 g
- Product dimensions (L x D x H): 420x325x295 mm
- Waste container capacity: 8 serv
- Dimensions of product (W x D x H): 420 x 325 x 295 mm
- Water tank capacity: 1 L

Technical specifications

- Voltage: 230 V
- Capacity bean container: 180 g
- Cord length: 0.8 m
- Frequency: 50 Hz
- Capacity water tank: 1 L
- Capacity waste container: 8 serv
- Max. cup height: 95 mm
- Pump pressure: 15 bar
- Water boilers: 1

General specifications

- Suitable for: Whole coffee beans
- Cups at the same time: 2
- Ease of cleaning and maintenance: Automatic rinse cycle, Removable brewing group
- Ease of use and comfort: Removable drip tray, Removable water tank
- Special functions: Pre-brewing
- Coffee drinks: Espresso, hot water

Design

- Colour: Black and silver

Weight and dimensions

- Weight of product: 7.2 kg

Technical data

- Power: 1400 W
- Voltage: 230 V
- Pump Pressure: 15 bar
- Frequency: 50 Hz

Finishing

- Material boiler: Stainless steel
- Material of main body: Plastic
- Material drip tray: Stainless steel
- Material of spout: Plastic

Service

- 2 year guarantee

Sustainability

- Power consumption brewing: 1400 W

