



Philips Saeco Syntia
Super-automatic
espresso machine

- Xelsis
- Focus



HD8942/12

Love your own favourite coffee speciality

Up to 9 fully customisable coffee specialities

With the Xelsis, each and every family member can enjoy his or her favourite coffee speciality. Up to 9 coffee specialities can be fully personalised.

Easy to clean and maintain

- Always a clean machine thanks to auto-clean and descaling

Multi-beverage

- Up to 9 fully customisable coffee specialities
- Perfect milk froth thanks to the integrated milk carafe

Bean-to-cup customisation

- Boost coffee crema and body
- Patented intelligent adjustable milk froth
- Full bean-to-cup customisation

Easy to use

- Ergonomic in day to day operation

Easy to use

- Immediate beverage selection

 **Saeco**

Highlights

Crema and body boost



This Saeco features our patented crema and body boost. This dial, conveniently located at your machine's spout, allows you to smoothly adjust the counter pressure, changing your espresso's body and crema. Try it yourself and find your favourite taste.

Adjustable milk froth



Only the Saeco coffee machine offers an intelligent milk froth adjustment system. Simply select the level of froth you'd like via the beverage menu.

Immediate beverage selection



Whether you want a cappuccino or an espresso, with the immediate beverage

selection you can enjoy your personally customised beverage speciality at the touch of a button

Auto-cleaning and descaling



Saeco designed this espresso machine to automatically clean its coffee circuit with water when starting up or switching off to deliver a great, fresh taste with each cup of coffee. Regular descaling prolongs your espresso machine's life. This machine will not only prompt when descaling is needed, the automated descaling process will start and guide you with clear on-screen messages when you have to intervene. Descaling has never been so easy!

Removable brewing group



The brewing group is at the heart of every fully automatic coffee machine and it should always be kept clean. A task that doesn't get any more convenient than with a Saeco: remove, rinse and re-insert — finished.

Full customisation



Everything just the way you like it: With this coffee machine you can choose your favourite coffee blend and adjust coffee length, intensity, temperature, crema and body structure until they all meet your personal taste perfectly.

Ergonomic day to day



Saeco is a synonym for convenience: refilling beans or water, emptying the coffee-dump box or the drip tray, all compartments of the full automatic coffee machine are directly accessible.

9 personalised beverages

With Saeco Xelsis you have a wide choice of beverages from espresso to latte macchiato. You can personalise each coffee speciality, adjusting both coffee and milk settings to how you want them.

Specifications

Easy to use

- Usage: Adjustable coffee dispenser, Bypass for grinded coffee, Cup-holding surface, Frontal access to all functions, Instant steam (2 boilers), Removable brewing group, Removable water tank
- Cleaning and maintenance: Automatic coffee circuit rinse, Automatic milk circuit rinse, Descaling cycle

Weight and dimensions

- Product dimensions (L x D x H): 280 x 370 x 420 mm
- Product weight: 13.9 kg
- Coffee bean capacity: 350 g
- Waste container capacity: 14 serv
- Weight: 13,9 kg
- Maximum cup height: 150 mm
- Milk carafe capacity: 0.5 L
- Water tank capacity: 1.6 L

Technical specifications

- Cord length: 80 cm
- Boiler material: Stainless steel (Inox)
- Voltage: 230 V
- Supported coffee types: Whole coffee beans, Ground coffee
- Power: 1500 W

- Frequency: 50 Hz
- Country of origin: Made in Italy, Designed in Italy
- Water pressure in pump: 15 bar (perfect espresso)
- Number of water boilers: 2 boilers (instant steam)
- Removable brewing group

Perfect Espresso

- Espresso technology: Saeco adapting system, Aroma-system: pre-brewing, SBS: creme adaptor, Cup warmer

Multi-Beverage

- Milk Variations: Frothing degree adaptor, Integrated auto milk function, Milk quantity selector, Removable milk carafe

Service

- 2-year worldwide guarantee

Technical data

- Power: 1500 W
- Voltage: 230 V
- Pump Pressure: 15 bar
- Frequency: 50 Hz

Sustainability

- Automatic Standby Option



Issue date 2022-06-21

Version: 1.1.1

© 2022 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com