



Philips ClearTouch
Garment Steamer

2000 W

Adjustable hanger, hang&lock
3 steam levels
Pleat maker, glove

GC536/39

Remove creases in no time

Designed for powerful performance and convenience

The new Philips ClearTouch garment steamer is designed for powerful crease removal in a few strokes. Its contemporary, unique design is accompanied by smart features and powerful steam that will make ironing both easier and faster.

Easy to use

- Easy Rinse descaling function
- Adjustable pole
- Hanger with hang&lock feature for stability during steaming
- Detachable, transparent water tank with hygienic water inlet

Quick crease removal

- Extra powerful steam
- XL Stainless steel steam plate for faster results
- 3 steam levels

Perfect pleats made easy

- Pleats made easy with pleat making accessory

Maximum safety

- Safe to use on delicate fabrics, like silk
- Glove for extra protection during steaming
- PVC free silicon steam hose

PHILIPS

Highlights

Extra powerful steam



Powerful steam is blown through the nozzles, enabling you to remove creases with only a few strokes.

Adjustable pole



Integrated adjustable pole for hanging your garments while using the steamer. It is collapsible for easy storage.

PVC free silicon steam hose



The steam hose is made of silicon material which is the safe and healthy choice for use with steam. As the safety and health of your family is important, no PVC is used in the steam hose.

3 steam levels



Set your preferred steam level for optimal results on different kinds of garments.

Detachable water tank



1.2 L detachable water tank with special water inlet for extra hygiene.

Safe on all garments



The steamer is safe to use on all fabrics. It is a great solution for delicate fabrics like silk.

XL Stainless steel steam plate



The steamer head has an XL stainless steel steam plate which delivers faster results.

Easy Rinse descaling function



Prolong the lifetime of your appliance by using the Easy Rinse descaling function regularly.

Glove for extra protection



Included is a glove that protects your hand during steaming.

Specifications

Easy to use

- Water tank capacity: 1200 ml
- Safe on all ironable fabrics: Even delicates like silk
- Soleplate name: XL steam plate
- Detachable water tank
- Refill any time during use
- Tap water suitable
- Power cord length: 1.6 m
- Silicone steam hose
- Special water inlet: For extra hygiene

Accessories included

- Adjustable pole
- Garment hanger
- Glove for extra protection
- Pleat maker

Fast crease removal

- Power: 2000 W
- Continuous steam: 40 g/min
- Voltage: 240 V
- Variable steam: 3 levels

Scale management

- Descaling and cleaning: Easy Rinse

Size and weight

- Weight of iron: 3.7 kg
- Packaging dimensions (WxHxL): 40x45x33.3 cm
- Product dimensions (WxHxL): 33x172x33 cm
- Total weight with packaging: 5.7 kg

Green efficiency

- User manual: 100% recycled paper



Issue date 2022-05-12

Version: 1.1.1

© 2022 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com