



**Saeco Exprelia Evo
Super-automatic
espresso machine**

- Brews 7 coffee varieties
- Integrated milk jug & frother
- Steel Black
- 5 step adjustable grinder



HD8855/47

Experience the fine art of making coffee with the hygiene-proof milk jug certified by VDE

With the Saeco Exprelia Evo, aspiring coffee experts can experience the thrill of preparing a cup as professionals would, with the ability to customize multiple drinks and the guarantee of a perfect hygiene

Ease of cleaning and maintaining

- Always a clean machine thanks to auto-clean and descaling

Ease of cleaning and maintaining

- Hygienic milk frothing thanks to automated dual cleaning

A variety of coffees customized to your taste

- Fine-tune the coffee's richness with adjustable grinders
- Enjoy a crema layer as you like it with a twist of a knob
- Customize and save strength, length and milk foam settings


Advanced technology designed for coffee perfection

- Silky foam at one touch with Double Chamber milk technology
- Milk specialties without the wait thanks to a double boiler

High comfort is part of the experience

- The fully removable brewing group can be cleaned in no time

 **Saeco**



Highlights

Automatic dual cleaning carafe



This Saeco espresso machine comes with a fully automated dual clean function for its milk carafe. The dual cleaning uses two independent steam cycles to swiftly rinse your milk carafe after each coffee drink you prepare, for a fresh milk drink everytime. Hygienic milk frothing was never this easy.

Auto cleaning and descaling



Saeco designed this espresso machine to automatically clean its coffee circuit with water upon starting up or switching off of the machine, this delivers a great, fresh taste with each cup of coffee. Regular descaling prolongs your espresso machine's life. This machine will not only prompt when descaling is needed, the automated descaling process will start on your machine and guides you with clear on-screen messages when

you have to intervene. Descaling has never been so easy!

Professional double boiler



With 2 separate heating systems to cater for both the optimal coffee or milk frothing temperatures, this Saeco fully automatic espresso machine guarantees professional performance and speed everytime. You are able to prepare as many latte macchiatos and cappuccinos as you wish, one after the other and each just as good as the previous without waiting.

100% Ceramic grinders



Our grinders are made of high-tech ceramic: exceptionally hard and precise. Fresh beans are gently ground, without risk of overheating: extracting all the best flavors and aroma,

delivering a superior coffee taste for at least 20,000 cups.

Refine crema and body quality



Enjoy a crema layer just the way you like it and discover a wide spectrum of tastes, all with the twist of a knob! You control the coffee flow and brew pressure to vary the body and thickness of the crema with one easy move. Turn it left for a luxurious, thick crema layer and an intense and full bodied espresso; Or turn it right for a smooth, lighter tasting coffee with less crema.

Removable brewing group



Efficiency and ease of use were key inspirations when Saeco invented the first brewing group 30 years ago. And to this day, it still proves to be an inspired, resolute piece of technology. As always, it's so simple to clean – just remove it and wash it under the tap for a few seconds, then re-insert it just as easily.

Specifications

Weight and dimensions

- Dimensions of product (WxDxH): 245 x 360 x 420 mm

Country of origin

- Made in: Italy

Technical specifications

- Voltage: 120 V
- Capacity bean container: 300 g
- Cord length: 0.8 m
- Frequency: 60 Hz
- Capacity milk carafe: 500 L
- Capacity water tank: 1.5 L
- Capacity waste container: 11 servings
- Max. cup height: 152 mm
- Water boilers: 2
- Pump pressure: 15 bar

General specifications

- Suitable for: Whole coffee beans, ground coffee powder
- Cups at the same time: 2
- Ease of cleaning & maintenance: Automatic descaling cycle, Automatic rinse cycle, Removable brewing group, Dishwasher-safe parts, Automatic carafe cleaning
- Customizing per drink: Adjustable coffee strength
- Ease of use and comfort: Removable spout,

- Removable water tank, Removable drip-tray, Display
- Special functions: Automatic milk frother, Integrated carafe, Pre-brewing, Steam option, Ceramic grinder, Crema adjustment knob, Manual milk frother Pannarello, Hot water option
- Type of boiler: Stainless steel boiler
- Type of carafe: Basic carafe
- Type of display: LCD
- Coffee drinks: Espresso, Cappuccino, hot water, Café Crème, frothed milk, Espresso Macchiato, Latte Macchiato

Design

- Color: Black, Stainless steel

Weight and dimensions

- Weight of product: 16.1 kg

Finishing

- Material of main body: Stainless steel
- Material boiler: Stainless steel (Inox)
- Material water tank: Plastic

Service

- 1-year guarantee

Sustainability

- Power consumption brewing: 1400 W