



Philips
Handheld vacuum cleaner

9.6 V

FC6090

High power, great results

Tackles any job easily

The new Philips FC6090 (9.6 V) gives you fast and effective cleaning wherever you need it. The cyclonic airflow and 2-stage filtration system guarantee lasting performance to tackle any job easily.

Lasting cleaning performance

- Cyclonic airflow and 2-stage filtration system

Always at hand

- Smart-design charging base for wall or table

Easily cleans delicate surfaces and narrow spaces

- Brush tool, crevice tool and bendable crevice tool

Easy-to-clean nozzle

- Detachable dishwasher-proof nozzle

Fast and effective cleaning

- 9.6 V rechargeable appliance with cyclonic airflow

PHILIPS

Highlights

9.6 V rechargeable appliance with cyclonic airflow



The Philips Mini Vac's cyclonic airflow keeps the dirt inside rotating to ensure optimal, high suction power and cleaning performance that lasts.

Exceptionally quiet



The Philips Mini Vac, with its powerful motor, is exceptionally quiet thanks to its special streamlined design. The comfortable noise level allows you to tidy up your home any time you want to.

Detachable dishwasher-proof nozzle



The Philips Mini Vac is also easy to maintain. If the nozzle needs cleaning, you simply put it in the dishwasher. That way you've always got a spotless, dirt-free Mini Vac at hand.

Smart-design charging base for wall or table



You can store the Philips Mini Vac on a convenient charging base, against a wall or on a table. This means the Philips Mini Vac, with its powerful rechargeable battery, is always ready when you are.

Brush tool, crevice tool and bendable crevice tool



The Philips Mini Vac comes with a number of accessories to tackle any job with ease. The soft brush attachment is gentle on delicate surfaces and the bendable crevice tool and crevice tool let you clean even those awkward, hard-to-reach places.

Cyclonic and 2-stage filter



The Philips MiniVac's cyclonic airflow keeps the dirt inside rotating to ensure optimal high suction power and lasting cleaning performance. Its 2-stage filtration system ensures that, once inside, the dirt cannot escape. The first filter blocks most dirt, while the second filter traps the finer dust particles.

Specifications

Weight and dimensions

- Dimensions of packaging (L x W x H): 195 x 190 x 426 mm
- Appliances per A-box: 4
- Dimensions of A-box (L x W x H): 403 x 393 x 444 mm

Performance

- Battery voltage: 9.6 V
- Charging time: 16-18 hour(s)
- Runtime: 10 min
- Vacuum (max): 4.1 kPa
- Suction power (max): 19 W
- Noise level (Lc IEC): 78 dB
- Airflow (max): 810 l/min

Design

- Colour: Velvet white

Usability

- Special features: Battery low indication, Charging indication, Soft touch handle

Nozzles and accessories

- Other accessories: Charging base

Filtration

- Dust capacity: 0.5 L
- Filter system: 2-stage

