

PHILIPS

wet & dry electric shaver
with precision trimmer

Shaver series 7000

GentlePrecision blade system

Comfort rings

50 min cordless use/1 hr charge

S7370/12



Smooth glide, sensitive shave

Philips' no. 1 on sensitive skin*

The Philips series 7000 protects against the key signs of skin irritation. SkinGlide rings with anti-friction coating enable the shaver to glide effortlessly across your face. Its blades cut close and protect skin, even with 3-day stubble.

Easy to use

- Intuitive display with 1-level battery indicator
- 50 minutes of cordless shaving
- Shaver can be rinsed clean under the tap
- Comes with a 2 year guarantee

A close and smooth shave

- Blades protect skin and cut close even with three-day stubble

Designed for maximum skin comfort

- SkinGlide rings with anti-friction coating for smooth glide
- Aquatec gives you a comfortable dry or refreshing wet shave
- 5-direction flex heads follow contours with less pressure

Get the most out of your shaver

- Even up your moustache and sideburns

Highlights

SkinGlide rings



Experience a more comfortable shave with anti-friction SkinGlide rings coated with microspheres. Thousands of tiny glass-like rounded spheres reduce friction and surface resistance between the shaver and the skin. This gives the shaver a smooth, easy glide and helps protect against skin irritation.

5-direction Dynamic Flex Heads



Our shaver heads flex easily in five directions, gently following all the contours of the face and neck. Less pressure is needed to shave closely and skin stress is minimised.

GentlePrecision PRO blades



Our updated cutting system has skin protection technology, designed to only cut hair not skin. V-shaped blades guide the skin away from the blades for a close, smooth shave — even on three-day stubble.

1 level battery indicator



The intuitive display shows relevant information, enabling you to get the best performance out of your shaver: 1-level battery indicator - cleaning indicator - battery low indicator - replacement head indicator - travel lock indicator

Aquatec Wet & Dry



Adapt your shave routine to your needs. With the Aquatec Wet & Dry, you can go for a comfortable dry shave or a refreshing wet shave. You can shave with gel or foam, even under the shower.

50 minutes of cordless shaving



one full shave. All Shaver series 7000 models are designed to operate only in cordless mode to ensure safety in wet environments.

Built to last



We back this Philips shaver with a 2 year guarantee. Our Series 7000 shavers are designed for performance and durability.

Fully washable shaver



Simply open the shaver head to rinse it thoroughly under the tap.

SmartClick Precision Trimmer



Refine and define your moustache and sideburns with the SmartClick precision trimmer—and complete your look with ease.

Specifications

Accessories

SmartClick: Precision trimmer
Pouch: Travel pouch

Software

Software update: Philips offers relevant software updates for a period of 2 years after the date of purchase

Power

Run time: 50 min / 17 shaves
Charging: 1 hour full charge, Quick charge 5 min for 1 shave
Automatic voltage: 100–240 V

Battery Type: Lithium-ion
Stand-by power: 0.15 W
Max power consumption: 5.4 W

Design

Handle: Ergonomic grip and handling
Frame colour: White
Front colour: Tesla ocean blue

Service

Replacement head: Replace every 2 yrs with SH70
2 year guarantee

Shaving Performance

Contour following: 5-direction DynamicFlex Heads
SkinComfort: SkinGlide Rings, SkinProtection System, Aquatec Wet and Dry
Shaving system: GentlePrecisionPRO Blades

Ease of use

Display: 1 level battery indicator, Battery low indicator, Cleaning indicator, Replace shaving heads indicator, Travel lock indicator
Wet and Dry: Wet and dry use
Cleaning: Fully washable
Operation: Cordless use, Unplug before use

