

# PHILIPS

Beard trimmer

Beardtrimmer series  
3000

0.5mm precision settings

Full Metal Trimmer

90 min cordless use/1h charge

Lift & Trim system



BT3227/15



## Effortless even trim

Lift & Trim system cuts 30% faster\*

This trimmer with the innovative Lift & Trim system lifts and captures more low-lying hairs for efficient, even trimming results. This way you will easily achieve the 3-day stubble, short beard or long beard look you want.

### Easy to use

- Longer lasting battery
- Simple maintenance
- Easy to grip
- Store and go
- Lights indicate when battery is low, empty, full or charging
- 90 minutes of cordless use or plug it in
- Adjusts to different length settings

### Easy even trimming

- Trims evenly and captures low-lying hairs
- Blades are double sharpened for faster trimming
- Skin-friendly blades for smooth skin

### Built to last

- 3 year\* warranty, worldwide voltage, no oil needed

# Highlights

## Lift & Trim system



Perfect for stubble, the Philips beard trimmer features our new Lift & Trim system: a comb that lifts and guides the hairs to the level of the blades for an even trim.

## Full metal blades



This trimmer comes with twice-sharpened full metal blades that cut more hairs in every pass for faster trimming.

## DuraPower technology



This beard trimmer uses DuraPower technology to reduce friction on the blades, preserve the motor, and keep your battery going four times longer.

## Skin-friendly blades



Designed to prevent scratches and irritation, the blades have rounded tips for smoother skin contact.

## Precision Dial - 20 settings

An effective beard trimmer that cuts to the exact length you're after. Just spin the zoom wheel to one of 20 length settings between 0.5 and 10mm in 0.5mm increments.

## 90 min corded/cordless use

Charge your trimmer for 1 hour to get 90 minutes of cordless use or use it plugged in while charging.

## Battery indicators

The battery indicators in this trimmer let you know what your battery status is: Low, empty, charging or full. This way, you can charge your trimmer on time and fully, so you won't end up with an empty battery in the middle of your trim.

## Easy to clean



Detach the head of your Philips beard trimmer and rinse it under the tap for easy cleaning. Then dry it before you put it back on the appliance.

## Ergonomic design



A fast trimmer that's comfortable to hold and use. So you can handle those hard-to-reach areas more easily.

## Built for durability



We back this Philips trimmer with a 3 year\* worldwide warranty. You'll never need to oil it, and it's compatible with all worldwide voltages.

## Travel and storage pouch



The included travel pouch keeps everything together when you're at home, at the gym or on-the-go.

# Specifications

## Power

**Battery Type:** NiMH

**Automatic voltage:** 100-240 V

**Charging:** 1 hour full charge

**DuraPower technology:** 4x longer battery life

**Run time:** 90 minutes

## Cutting system

**Cutting element:** Full metal blades

**Cutter width:** 32 mm

**Range of length settings:** 0.5 up to 10 mm

**Precision (size of steps):** By 0.5 mm

**Non-scratching teeth:** For more comfort

## Design

**Handle:** Ergonomic Easy Grip

## Ease of use

**Cleaning:** Rinseable attachments

**Display:** Battery low indicator, Battery empty indicator, Charging indicator, Battery full indicator

**Zoom wheel:** Easily adjust length settings

**Operation:** Corded & Cordless use

## Accessories

**Maintenance:** Cleaning brush

**Pouch:** Storage pouch

**Comb:** Lift & Trim system

## Create the look you want

**Number of length settings:** 20 integrated length settings

## Service

**2-year warranty:** Yes, Plus 1 year with product registration on Philips website

**No oil needed**

