



Philips Bodygroom series  
7000  
Showerproof body  
groomer

**Skin contour system**

Integrated comb, 3-11mm  
50mins cordless use/1h charge  
Dual-sided design



**TT2040/33**

## Powerful trim, precise shave

### Everywhere below the neck

The ultimate all-in-one solution, the Series 7000 features an integrated trimmer on one side and a skin-friendly, contour system on the other, for a comfortable and convenient trim or shave, anywhere below the neck.

**Easy to use**

- 50 minutes cordless use after a 1-hour charge
- Easy to clean and use in or out of the shower
- Easy to grip

**Skin-friendly performance**

- Rounded tips and hypoallergenic foil for skin comfort
- Includes adjustable comb, trims hair from 3-11mm
- Adapts to the surface of your body for a precise shave

**Built to last**

- Warranty for purchase protection

**PHILIPS**

Showerproof body groomer  
Skin contour system Integrated comb, 3-11mm, 50mins cordless use/1h charge, Dual-sided design

TT2040/33

## Highlights

### Skin contour system



The skin contour system catches and cut hairs of different lengths, without the need for multiple tools or skin contact with sharp edges. The bi-directional trimmers cut longer hairs, which are shaved by the foil for a closer result. The added flexibility of the contour system follows every angle and surface of your body for precisely the look you want.

### Skin-friendly tips and foil



The skin comfort system features a hypo-allergenic foil and rounded tips to protect your skin while shaving.

### Integrated trimmer with comb



The integrated trimmer and adjustable comb with 5 length settings is designed to offer more power to cut even the thickest hair. To maintain your desired hair length or get a natural look, adjust the comb to a length between 3-11mm. You can use the shaving system on the other side, for a closer result.

### Rechargeable battery power



High-power NiMH battery for full body use, with 50 minutes of cordless use after a 1-hour charge. The battery light indicates power status, when the battery is low or full.

### 100% showerproof



Provides a comfortable and close result in and out of the shower. The bodygroomer is 100% showerproof, so you can simply rinse it clean when you've finished. For longer hair, trimming performance may be better on dry hair.

### Ergonomic grip



Your body groomer is easy to hold and manoeuvre, with a rubber ergonomic grip to help you keep control while you trim.

### Built to last



All of our grooming products are built to last. They come with a 2 year warranty and they never need to be oiled.

# Specifications

## Create the look you want

- Number of length settings: 5 integrated length settings

## Accessories

- Stand: Charging stand

## Power

- Battery type: Ni-MH
- Run time: 50 minutes
- Charging: 1 hour full charge

## Design

- Handle: Ergonomic grip & handling

## Consumer Trade Item

- Height: 24.5
- Width: 15
- Length: 5.8
- Net Weight: .349
- Gross Weight: .483
- GTIN: 8710103617822
- Country of origin: CN
- Harmonized system code: 851020

## Outer Carton

- Height: 26
- Width: 15.8
- Length: 24
- Gross Weight: 1.934
- GTIN: 18710103617829

## Service

- 2-year worldwide guarantee

## Cutting system

- Cutter width: 32 mm
- Shaving element: Foil with two pre-trimmers
- Trimming element: Integrated
- Skin comfort: Skin contour system, Comfort in sensitive areas

## Ease of use

- Maintenance free: No oil needed
- Wet & Dry: Fully washable, Showerproof and easy cleaning
- Operation: Cordless use
- Secured length settings



Issue date 2024-02-16

Version: 2.0.1

EAN: 87 10103 61782 2

© 2024 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)