



Philips Norelco Shaver
8500
Wet & dry electric shaver,
Series 8000

UltraTrack heads
GyroFlex 3D contouring system
60 min shaving, 1 hr charge

1260X/40

Series 8000 - Ultimate shaving experience

with GyroFlex 3D system

The Philips Norelco Shaver 8500 (formerly called SensoTouch 3D) provides the ultimate shaving experience. The Gyroflex 3D system follows every contour of your face and shaves every hair with fewer strokes with its UltraTrack heads.

Follows the unique contours of your face

- Philips GyroFlex 3D system adjusts seamlessly to every curve

Sensationally smooth shave

- UltraTrack heads catch every hair with just a few strokes
- Patented Lift & Cut Action for a closer shave

An electric shaver which takes care of your skin

- Aquatec seal for comfortable dry & refreshing wet shaves
- Smooth, low-friction SkinGlide to minimize irritation

Shave with perfect control and precision

- Easy grip handle with ergonomic grip for close control
- Skin-friendly precision trimmer

PHILIPS
NORELCO

Wet & dry electric shaver, Series 8000

UltraTrack heads GyroFlex 3D contouring system, 60 min shaving, 1 hr charge

1260X/40

Highlights

GyroFlex 3D Shaver



GyroFlex 3D contour-following heads of the shaver adjust seamlessly to every curve of your face, minimizing pressure and irritation on your skin.

UltraTrack Shaver Heads



Get a close shave that minimizes skin irritation. The shaving head has 3 specialized tracks: slots for normal hair; channels for long or flat laying hair; and holes for the shortest stubble on your face.

Aquatec



The Aquatec wet & dry seal of the electric shaver lets you choose how you prefer to shave.

You can get a comfortable dry shave or a refreshing wet shave using a shaving gel or foam for extra skin comfort.

SkinGlide



The low-friction SkinGlide shaving surface of the electric shaver slides smoothly along your skin for a close easy shave.

Easy grip



The easy grip shaver handle has an ergonomic grip with anti-slip coating, ensuring close control for an extra precision shave.

Precision trimmer



The unique skin-friendly precision trimmer system is built to avoid unnecessary skin contact. Easy to use for perfect moustache and sideburn trimming.

Super Lift & Cut Action



The dual blade system built into the shaver lifts hairs to cut comfortably below skin level for an even closer shave.

Specifications

Shaving Performance

- Contour following: GyroFlex 3D contour following
- Shaving system: UltraTrack shaving heads, Speed XL shaving heads, DualPrecision System, Patented Super Lift & Cut
- SkinComfort: SkinGlide
- Styling: Skin friendly precision trimmer

Ease of use

- Wet & Dry: Wet and dry use
- Cleaning: Washable
- Charging: 1 hour, Rechargeable, Cordless, Quick charge
- Display: 5 level battery indicator, Battery low indicator, Charge indicator, Travel lock, Cleaning indicator, Replace shaving heads indicator
- Shaving time: Up to 20 days

Accessories

- Pouch: Soft pouch

- Maintenance: Cleaning brush, Protective cap
- Stand: Charging stand

Design

- Handle: Slim handle, Easy grip, Anti-slip grip
- Finishing: Metallic frame, LED Display
- Color: Silver

Power

- Battery Type: Lithium-ion
- Stand-by power: 0.15 W
- Run time: 60 minute(s)
- Max power consumption: 5.4 W
- Automatic voltage: 100-240 V

Service

- 2-year guarantee
- Replacement head: Replace every yr with RQ12



Issue date 2022-07-24

Version: 11.1.1

EAN: 00 07502 00131 63

© 2022 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com