



Philips Bodygroom series  
3000  
Showerproof body  
groomer

Skin comfort system  
3 combs, 3-7mm  
50mins cordless use/8h charge



BG2026/15

## Close trim, comfortable shave

Everywhere below the neck

The Series 3000 is designed to power through hair, without compromise on skin comfort. Whether on the chest or hard-to-reach areas like the back, you can shave with the skin comfort system or trim using the 3, 5 or 7mm length combs.

### Easy to use

- 50 minutes cordless use after an 8-hour charge
- Easy to clean and use in or out of the shower
- Easy to grip

### Skin-friendly performance

- Rounded tips and hypoallergenic foil for skin comfort
- Includes 3 combs for a 3, 5 or 7mm trim
- Confidently trim or shave all body zones

### Built to last

- Warranty for purchase protection

**PHILIPS**

Showerproof body groomer  
Skin comfort system 3 combs, 3-7mm, 50mins cordless use/8h charge

# Highlights

## Skin comfort system

Designed to be safe and comfortable for underarms, chest & abs, back & shoulders, groin area and legs. The skin comfort system catches and cuts hairs of different lengths, without the need for multiple tools or skin contact with sharp edges. The bi-directional trimmers cut longer hairs, which are shaved by the foil for a closer result.

## Skin-friendly tips and foil



The skin comfort system features a hypo-allergenic foil and rounded tips to protect your skin while shaving.

## 3 combs included, 3-7mm



3 combs included for different body hair lengths. Attach the combs onto the shaving system, to trim hair to fixed length settings of 3mm, 5mm, or 7mm. You can use the shaving system without the combs, for a closer result. For thicker hair, pre-trimming with the fixed combs is recommended.

## Rechargeable battery power



High-power NiMH battery for full body use, with 50 minutes of cordless use after an 8-hour charge. The battery light indicates power status, when the battery is low or full.

## 100% showerproof

Provides a comfortable and close result in and out of the shower. The bodygroomer is 100% showerproof, so you can simply rinse it clean when you've finished. For longer hair, trimming performance may be better on dry hair.

## Ergonomic grip

Your body groomer is easy to hold and manoeuvre, with a rubber ergonomic grip to help you keep control while you trim.

## Built to last



All of our grooming products are built to last. They come with a 2 year warranty and they never need to be oiled.

BG2026/15

# Specifications

## Create the look you want

- Number of length settings: 3 fixed length settings

## Cutting system

- Cutter width: 32 mm
- Shaving element: Foil with two pre-trimmers
- Skin comfort: Skin comfort system, Comfort in sensitive areas

## Design

- Handle: Ergonomic grip & handling

## Accessories

- Stand: Charging stand

## Ease of use

- Maintenance free: No oil needed
- Wet & Dry: Fully washable, Showerproof and easy cleaning
- Operation: Cordless use
- Secured length settings

## Power

- Charging: 8 hours full charge
- Run time: 50 minutes
- Battery type: Ni-MH

## Service

- 2-year worldwide guarantee



Issue date 2022-06-25

Version: 5.0.1

© 2022 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)