

# PHILIPS

## NORELCO

Wet & dry electric  
shaver, Series 6000

Shaver 6900

DualPrecision heads

GyroFlex 2D contouring system

50 min shaving, 1 hour charge

Jet clean system

1180X/42



### Series 6000 - Soft touch, smooth shave

The Philips Norelco Shaver 6900 (formerly called SensoTouch 2D) has a soft touch for a smooth shave. The Gyroflex 2D system adjusts easily to your face and the JetClean System washes, lubricates, dries and charges your shaver.

#### **A shaver which adjusts to the curves of your face**

- GyroFlex 2D system adjusts easily to the curve

#### **Close and comfortable shave**

- DualPrecision shaves even the shortest stubble
- Patented Lift & Cut Action for a closer shave

#### **An electric shaver which takes care of your skin**

- Aquatec seal for comfortable dry & refreshing wet shaves
- Smooth, low-friction SkinGlide to minimize irritation

#### **Shave with perfect control and precision**

- Precision trimmer for perfect moustache, sideburn trimming

#### **A brand new shave every day**

- Jet Clean system cleans, lubricates and charges the shaver

# Shaver 6900

Wet & dry electric shaver, Series 6000

1180X/42

## Highlights

### DualPrecision



DualPrecision shaving heads have slots to shave the normal hairs and holes to shave even the shortest stubble.

### SkinGlide



The low-friction SkinGlide shaving surface of the electric shaver slides smoothly along your skin for a close easy shave.

### GyroFlex 2D



GyroFlex 2D contour-following system of the shaver adjusts easily to the curves of your face, minimizing pressure and irritation for a close shave.

### Aquatec



The Aquatec wet & dry seal of the electric shaver lets you choose how you prefer to shave. You can get a comfortable dry shave or a refreshing wet shave using a shaving gel or foam for extra skin comfort.

### Jet Clean system



Jet Clean system cleans and lubricates the blades and charges the battery after every use.

### Precision trimmer



Precision trimmer for perfect moustache and sideburn trimming.

### Super Lift & Cut Action



The dual blade system built into the shaver lifts hairs to cut comfortably below skin level for an even closer shave.

# Shaver 6900

Wet & dry electric shaver, Series 6000

1180X/42

## Specifications

### Accessories

**Pouch:** Soft pouch

**Maintenance:** Cleaning brush, Protective cap

**Stand:** Charging stand

**Jet Clean**

### Power

**Battery type:** Lithium-ion

**Run time:** 50 minute(s)

**Stand-by power:** 0.15 W

**Max power consumption:** 5.4 W

### Design

**Color:** Red

**Finishing:** Seamless foil, LED Display

**Handle:** Slim handle, Anti-slip grip

### Service

**Replacement head:** Replace every 2 yrs with RQ11  
2-year guarantee

### Shaving Performance

**Contour following:** GyroFlex 2D contour following

**SkinComfort:** SkinGlide

**Shaving system:** DualPrecision System, Patented  
Super Lift & Cut

**Styling:** Precision trimmer

### Ease of use

**Charging:** 1 hour, Rechargeable, Cordless, Quick  
charge

**Cleaning:** Washable

**Display:** 5 level battery indicator, Battery low  
indicator, Charge indicator, Travel lock

**Wet & Dry:** Wet and dry use, Jet Clean

**Shaving time:** Up to 17 days

**Jet Clean:** Cleans, lubricates and charge

