



Philips Norelco Shaver  
6900  
Wet & dry electric shaver,  
Series 6000

**DualPrecision heads**  
GyroFlex 2D contouring system  
50 min shaving, 1 hour charge  
Jet clean system

1180X/42

## Series 6000 - Soft touch, smooth shave

The Philips Norelco Shaver 6900 (formerly called SensoTouch 2D) has a soft touch for a smooth shave. The Gyroflex 2D system adjusts easily to your face and the JetClean System washes, lubricates, dries and charges your shaver.

### **A shaver which adjusts to the curves of your face**

- GyroFlex 2D system adjusts easily to the curve

### **Close and comfortable shave**

- DualPrecision shaves even the shortest stubble
- Patented Lift & Cut Action for a closer shave

### **An electric shaver which takes care of your skin**

- Aquatec seal for comfortable dry & refreshing wet shaves
- Smooth, low-friction SkinGlide to minimize irritation

### **Shave with perfect control and precision**

- Precision trimmer for perfect moustache, sideburn trimming

### **A brand new shave every day**

- Jet Clean system cleans, lubricates and charges the shaver

**PHILIPS**  
**NORELCO**

## Wet & dry electric shaver, Series 6000

DualPrecision heads GyroFlex 2D contouring system, 50 min shaving, 1 hour charge, Jet clean system

1180X/42

# Highlights

### DualPrecision



DualPrecision shaving heads have slots to shave the normal hairs and holes to shave even the shortest stubble.

### Aquatec



The Aquatec wet & dry seal of the electric shaver lets you choose how you prefer to shave. You can get a comfortable dry shave or a refreshing wet shave using a shaving gel or foam for extra skin comfort.

### SkinGlide



The low-friction SkinGlide shaving surface of the electric shaver slides smoothly along your skin for a close easy shave.

### Jet Clean system



Jet Clean system cleans and lubricates the blades and charges the battery after every use.

### Precision trimmer



Precision trimmer for perfect moustache and sideburn trimming.

### GyroFlex 2D



GyroFlex 2D contour-following system of the shaver adjusts easily to the curves of your face, minimizing pressure and irritation for a close shave.

### Super Lift & Cut Action



The dual blade system built into the shaver lifts hairs to cut comfortably below skin level for an even closer shave.

# Specifications

## Shaving Performance

- Shaving system: DualPrecision System, Patented Super Lift & Cut
- Contour following: GyroFlex 2D contour following
- SkinComfort: SkinGlide
- Styling: Precision trimmer

## Ease of use

- Wet & Dry: Wet and dry use, Jet Clean
- Charging: 1 hour, Rechargeable, Cordless, Quick charge
- Display: 5 level battery indicator, Battery low indicator, Charge indicator, Travel lock
- Cleaning: Washable
- Shaving time: Up to 17 days
- Jet Clean: Cleans, lubricates and charge

## Design

- Handle: Slim handle, Anti-slip grip

- Finishing: Seamless foil, LED Display
- Color: Red

## Accessories

- Pouch: Soft pouch
- Maintenance: Cleaning brush, Protective cap
- Stand: Charging stand
- Jet Clean

## Power

- Battery Type: Lithium-ion
- Stand-by power: 0.15 W
- Run time: 50 minute(s)
- Max power consumption: 5.4 W

## Service

- 2-year guarantee
- Replacement head: Replace every 2 yrs with RQ11



Issue date 2022-07-22

Version: 7.1.1

© 2022 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)