



Philips
Conical Curler

Conical barrel (13-25mm)

Silky smooth ceramic coating
130 - 200 C temperature
Auto shut-off



HP8618/00

Healthier way to perfect curls and waves

thanks to the Curl Ready Indicator

Hyper sumptuous, soft curls radiating shine. Voluptuous, chic waves with lots of volume and thickness... With the new Philips conical curler Care CurlControl you can create different curling styles with no compromises on hair care

Ease of use

- Automatic shut-off after 60 min
- Safety stand for easy use
- Universal voltage
- Key-lock function to avoid unintentional switching
- Ready to use indicator on LCD screen

Beautifully styled hair

- Conical barrel for different types of curls and waves
- 200°C top temperature for perfect styling results

Less hair damage

- Unique indicator lets you know when your curl is ready
- SilkySmooth ceramic coating is twice as smooth on your hair
- Digital settings let you adjust the curler to your hair type

PHILIPS

Conical Curler

Conical barrel (13-25mm) Silky smooth ceramic coating, 130 - 200 C temperature, Auto shut-off

HP8618/00

Highlights

Curl Ready indicator



Unique Curl Ready indicator lets you know when your curl is ready by giving a “beep” signal. This innovative feature helps you get beautiful curls and waves while helping prevent hair overtreating. Just choose one of three curling times and press the button after having wrapped the hair around the barrel. Refer to user manual to see recommendations of our hair experts on how to select a curling time depending on your hair type and the look you want to achieve.

SilkySmooth ceramic coating

The SilkySmooth ceramic barrel, which is twice as smooth as ceramic barrel, ensures less friction and smoother hair release for shinier, healthier hair.

Digital settings



Digital settings allow you to choose the temperature (130 - 200°C) and the curling time (5, 8, or 10 seconds) that suit your hair type and desired look.

Conical shape of barrel



With the conical curler (Ø13-25 mm) you can create different types of curls and waves: from tight ringlets to loose, natural looking curls and waves. It is fast and easy, no more kinks. Add volume to your hair by creating variations on the theme of curls!

Safe usage



Some hair straighteners and curling irons have been equipped with an automatic shut-off

feature. This feature has been designed to provide peace of mind. If left on, the appliance will automatically switch off after 60 min.

Key-lock function



You are always in control. No more accidental temperature change with the key-lock function.

Safety stand

The safety stand enables you to put the curler down safely during use.

200°C top temperature



Top temperature of 200°C guarantees perfect results even for thick hair, while minimizing hair damage.

Ready to use indicator

Temperature symbol stops blinking when the curler is heated up and ready to use.

Conical Curler

Conical barrel (13-25mm) Silky smooth ceramic coating, 130 - 200 C temperature, Auto shut-off

HP8618/00

Specifications

Technical specifications

- Color/finishing: black-white
- Cord length: 1.8 m
- Heating time: 60s
- Barrel diameter: 13-25 mm
- Maximum temperature: 200 °C
- Voltage: worldwide
- Heater type: PTC
- Temperature range: 130-200

Features

- 'Curl ready' indicator
- Ceramic coating

- Ready for use indicator
- Cool tip
- Swivel cord
- Hanging loop

Hair type

- End result: Bouncy curls and waves
- Hair thickness: Medium, Thick, Thin
- Hair length: Long, Medium

Service

- 2-year worldwide guarantee



Issue date 2022-06-25

Version: 11.1.1

© 2022 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com