



Philips ProTouch 2-in-1
Garment Steamer

2200W, 90g steam boost
2-in-1 with ErgoFit board
5 steam levels
Double pole with Hang&Lock



GC618/66

Professional results for all garments

With PureSteam technology and ErgoFit board

Thanks to the innovative PureSteam technology and tiltable ErgoFit board, the new ProTouch 2-in-1 garment steamer ensures powerful steam performance to give you professional and crisp results for years to come!*

More efficiency, less effort

- 5 steam settings for different kinds of fabric
- Auto steam stop for saving energy and water
- Select steam levels directly from the handle
- No descaling is needed, thanks to the PureSteam technology
- PureSteam technology ensures powerful steam over the years

Reliable and safe

- Safe to use on all garments
- PVC free silicon steam hose
- Automatically switches to standby mode for safety

Professional results

- Precision tips for challenging areas
- 90g steam boost for tough wrinkle removal
- Tiltable ErgoFit board to achieve crisp results
- Penetrating powerful steam with up to 3 bar pump pressure

PHILIPS

Highlights

Penetrating powerful steam



The innovative PureSteam technology is fundamentally different from other steamers. With up to 3 bar pump pressure, it generates powerful steam which penetrates deep into the garments, enabling you to remove creases with only a few strokes.

Steam boost

By long pressing the steam selection button on the handle, up to 90g powerful steam boost is triggered, helping you to remove tough wrinkles easily.

Powerful steam over the years



Other steamers are easy to lose steam performance over time due to scale build-up, even if you clean it regularly. With the innovative PureSteam technology, the heater is automatically descaled while generating steam. This prevents scale from building up. It is so effective that the steam is powerful for years to come*.

No descaling needed



Steamers need to be descaled regularly to ensure steam performance. With our new PureSteam technology, the heater is automatically descaled while generating steam, so you don't need to worry about it.

Tiltable ErgoFit board



The ErgoFit board is designed to suit how you steam. It can be tilted by 30°, which gives stable and comfortable support to make pleats and achieve crisp results. Also, the shoulder shape of the board provides a better fit for the garment.

Easy steam level selection



By pressing the steam selection button on the handle, you can easily change steam level for different fabrics - no need to bend down!

5 steam settings



Set your preferred steam setting for optimal results on different kinds of fabric.

Auto steam stop



When you want to pause during steaming, just put the steamer head on the dock and the steam will automatically stop, saving both energy and water

Precision tips



The Precision tips of the steamer head enable you to reach the challenging areas, such as the collar, the shoulder, and the in-between buttons, giving you precise results.

Specifications

Easy to use

- Safe on all ironable fabrics: Even delicates like silk
- Water tank capacity: 2000 ml
- Soleplate name: SmartFlow Gold steam plate
- Safety auto off
- Detachable water tank
- Auto steam stop
- Refill any time during use
- Tap water suitable
- Power cord length: 1.6 m
- Hose length: 1.3 m
- Hang&Lock
- Select steam level from handle
- Silicone steam hose
- Support for ironing: Tilttable ErgoFit board

Technology

- PureSteam Technology

Accessories included

- Brush
- Glove for extra protection
- Pants hanger

Fast crease removal

- Pressure: Max 3 bar pump pressure
- Power: 2200 W
- Steam boost: 90 g
- Continuous steam: up to 45 g/min
- Ready to use: <1.5 minute(s)
- Variable steam: 5 levels

Scale management

- Descaling and cleaning: Auto de-calc



Issue date 2022-06-17

Version: 1.1.1

© 2022 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com

* **Tested according to IEC protocol with hard water for 500 hours to simulate 10 years of usage time.