

# PHILIPS

## Epilator

### Satinelle Ice

Pink

HP6492/00



## Unique ceramic epilation system from Philips

Ice and massage for a more gentle hair removal

Thanks to the soothing properties of ice and an integrated massage system, the new Satinelle Ice significantly reduces the pain normally associated with epilation. The hypoallergenic ceramic disc system is also gentle on sensitive skin.

#### **Additional benefits**

- Additional shaving head
- Exfoliating body puff
- New ergonomic design
- Two speed settings

#### **Advanced pain reduction system**

- Click-on ice cooler
- Integrated massaging system
- Pivoting cooling head

#### **Unique ceramic epilating head**

- Curved epilating head
- Higher rotation speed
- Hypo-allergenic ceramic epilating head

# Highlights

## Click-on ice cooler

The patented ice cooler soothes the skin reducing the unpleasant feeling of epilation. Its pivoting head follows every curve of your body for optimal cooling and less pain.

## Pivoting cooling head

Follows the body's contours for maximum pain reduction during epilation and an immediate cooling and soothing effect on the skin afterwards.

## Integrated massaging system

Works with the skin cooler to distract from the sensation of epilation.

## Hypo-allergenic ceramic head

Better skin care by reducing the risk of allergic skin irritation.

## Curved epilating head

For improved grip on hair, ensuring that up to 95% of hairs are removed at the root in one stroke.

## Higher rotation speed

For more effective hair removal.

## Exfoliating body puff

Reduces ingrown hair.

## Additional shaving head

For smooth shaving of underarm and bikini areas.

## New ergonomic design

For easier handling.

## 2 speed settings

Speed 1 for fine hair, speed 2 for thicker hair.

# Specifications

## Weight and dimensions

**A-box dimensions:** 56,6 x 19,6 x 25,1cm (width x depth x height) mm

**F-box dimensions:** 19,6 x 9,4 x 23,5cm (width x depth x height) mm

**A-box weight:** 4222 g

**F-box weight:** 652 g

**No. of pieces per A-box:** 6 pcs

**Packaging design:** Fancy-box with 3D-window

## Accessories

Cleaning brush

Detachable shaving head

Exfoliation body puff

Insulation sleeve

Luxury storage pouch

## Technical specifications

**Number of catching points:** 24

**Voltage:** 100-240V (50-60 Hz) Automatica Voltage Selection V

**Power consumption:** 6 W

**Number of discs:** 25

**Power source:** AC (Mains)

**Pulling actions/second speed 1:** 880

**Motor:** DC-Motor 14V

**Pulling actions/second speed 2:** 1080

**RPM speed 1:** 2200 min

**RPM speed 2:** 2700 min

## Features

2 speed settings

Active massage system

Ceramic epilation system

Pivoting ice cooler

