

# PHILIPS

## Wake-up Light

Wake up with light

2 natural sounds

FM radio & Bedside lamp

HF3506/66



## Wake up with light, feeling more refreshed with a Wake-up Light that wakes you up naturally

Inspired by nature's sunrise the Philips Wake-up Light uses a unique combination of light and sound wakes you in a more natural way and feeling more refreshed. Making it easier to get out of bed.

### **Natural light wakes you gradually**

- Sunrise Simulation wakes you gradually
- Bedside light with 10 light settings
- Colour flow of sunrise: Bright Yellow

### **Natural sounds wake you gently**

- Choice of 2 different natural wake up sounds

### **Naturally designed around you**

- Snooze function
- 4 display brightness levels - adjust to your preference

### **Naturally proven to work**

- Developed by Philips, experts in light for over 100 years.
- The only Wake-up Light clinically proven to work

# Highlights

## Developed by Philips



Philips was founded over a 100 years ago as a company that produced and sold lightbulbs. Over 100 years Philips grew into a global company that brings innovation in lots of different areas. To this day lighting still is the soul of Philips. The Wake-up Light is proud to continue its heritage by building on years of knowledge and expertise of the world's most well know lighting expert.

## Proven by scientists



At this moment in time the Philips wake-up light is the only one scientifically proven to work. In order to make the Wake-up Light the best possible product it can be in genuinely waking you up naturally and energized we have done a lot of clinical research. This research was conducted by independent science facilities to study and prove the effects of the wake-up light on the overall wake up experience. This way we have proven, among other things, that the Philips Wake-up Light not only wakes you more naturally, but also more energized and that it improves your mood in the morning.

## Sunrise Simulation



Inspired by nature's sunrise, light gradually increases within 30 minutes until your room is filled with bright yellow light. This process of changing an increasing light stimulates your body to wake up naturally. By the time light has filled the room your chosen natural sound completes the wake up experience, leaving you ready for the day ahead.

## 2 natural sounds



At your set wake up time a natural sound will play to complete the wake up experience and ensure you are awake. The selected sound gradually increases in volume to your selected level within one and a half minute. There are two natural bird sounds you can choose from.

## Bedside Light



The sensitivity to light differs per person. In general, when using a higher light intensity a person needs less time to become fully awake. The 10 light intensities of the Wake-up light can be personalized and even be set up to 200 lux.

## Light; Yellow (1)

The light of the sunrise simulation moves from Yellow to bright Yellow.

## Snooze function



The sound stops when you tap the top of the product. After 9 minutes the sound will gently start playing again.

## 4 display brightness levels



The brightness of the display can change from high-medium-low-very low-none.

# Specifications

## Sound

Number of Wake-up Sounds: 2  
Music from smartphone / iPod: No  
FM Radio

## Logistic data

CTV code: 884350666  
Country of origin: China

## Safety

UV-free: UV-free

## Easy to use

Anti-slip rubber feet  
Charges iPhone/ iPod Touch: No  
Display brightness control: 4 settings  
Snooze type: Tap top to snooze

## Instore demo function

Number of alarm times: 1  
Snooze Duration: 9 minute(s)  
Controlled by iPhone App: No

## Well-being by light

Increase energy in morning  
Wake up gradually by light

## Natural light

Sunrise simulating process: 30 minutes  
Brightness settings: 10  
Light intensity: 200 lux  
Fall Asleep function: No  
Colors in sunrise simulation: Bright Yellow

## Technical

Box Dimensions (WxHxD): H200 x W200 x D130 mm  
Box Weight: 600 gram  
Cord Length EU/US: 150/180 CM  
Voltage: 100/240 V  
Frequency: 50/60 Hz  
Insulation Device: Class III  
Insulation Power Plug: Class II (double isolation)  
Replaceable Lamp: No  
Type of Lamp: Liteon SMD Lamp LED  
Product Dimensions: H 180mm x W 180mm x D 115mm  
Product Weight: 290 gram

