



Saeco Via Venezia  
Manual Espresso  
machine

• Silver

RI9367/01

## Taste the full Aroma of your Espresso

In a full die-cast body and professional quality

Professional Coffee quality in your kitchen. With a die-cast metal body combined with high capacity, and the patented pressurised filter Crema, you can delight your guests as a professional barista. Enjoy your espresso throughout preparation.

### **Authentic Italian Espresso**

- Pressurised Crema filter holder
- 15 bar pump
- Cup warmer

### **Simplicity and speed of use**

- Suitable for ground coffee and pods
- Delicious milk froth thanks to the classic milk frother

### **Everyday use**

- Long-lasting premium materials

### **Large espresso capacity**

- 2.9-litre water tank for high capacity

 **Saeco**



# Highlights

## Pressurised Crema filter



This special Crema filter guarantees a long-lasting, delicious Crema — whatever coffee blend you may choose.

## Ground coffee and pods



For your convenience you can choose between ground coffee and pods

## 15 bar pump



High pressure ensures that the entire aroma of the ground coffee is always fully extracted

## Long-lasting premium materials



The Saeco Manual Espresso machine features high-quality and durable housing material.

## Cup warmer



This feature allows you to not only store your espresso cups and glasses right on the espresso

machine, it also pre-heats them letting the aroma unfold even better and guaranteeing a long-lasting crema

## 2.9-litre water tank



The extra large water tank allows you to brew lots of coffee and allows for lots of steam uses, with less refilling.

## Classic milk frother



This Saeco espresso machine comes with the classic milk frother that baristas call a "Pannarello". It dispenses steam and is immersed in milk to prepare gorgeous milk foam. Unleash your inner barista by preparing your delicious milk specialties the traditional way!

# Specifications

## Weight and dimensions

- Product dimensions (L x D x H):  
270 x 375 x 345 mm
- Product weight: 8.2 kg
- Water tank capacity: 2.9 L

## Technical specifications

- Cord length: 80 cm
- Boiler material: Inox
- Supported coffee types: Coffee pods, Ground coffee
- Power: 950 W

## Features

- Hot water/Steam Nozzle

- Interface: Direct buttons
- Pannarello: Plastic
- Cup warmer
- Simultaneous brewing
- Filter holder: Pressurised "Crema"
- Suitable for pods

## Design

- Colour: stainless steel
- Materials and finishing: stainless steel

## Service

- 2-year worldwide guarantee