



Philips Azur Performer  
Plus  
Steam iron

Steam 50g/min; 200g steam boost

T-ionicGlide soleplate  
Safety Auto off + Anti-calc  
2600 Watts



GC4521/87

## Faster, Easier and Smarter

With our best gliding soleplate yet

The Philips steam iron Azur Performer combines powerful performance with ease of use. Combining easy Quick Calc Release with our 5-star-rated best-gliding T-ionicGlide soleplate and Safety Auto Off to give optimal ironing results, easily.

### Comfortable ironing

- Innovative CordGuide
- Auto Steam Control for the right steam for each garment
- Triple precision tip for optimal control and visibility
- Optimal weight for easier manoeuvrability over your garments

### Easy gliding on all fabrics

- T-ionicGlide: our best 5-star rated soleplate

### Safe ironing

- Self-Clean for effective calc removal
- Quick calc release to remove scale from your steamer
- Iron switches off automatically when left unattended

### Fast and powerful performance

- 2600 W for quick heat-up and powerful performance
- Steam output of up to 50 g/min for better crease removal
- Steam boost up to 200 g

# PHILIPS

Steam iron

Steam 50g/min; 200g steam boost T-ionicGlide soleplate, Safety Auto off + Anti-calc, 2600 Watts

GC4521/87

# Highlights

## 2600 W for quick heat-up



2600 W for quick heat-up and powerful performance.

## Steam up to 50 g/min



Continuous steam output of up to 50 g/min gives you the perfect amount of steam to efficiently remove all creases.

## Steam boost up to 200 g



The steam boost can be used for vertical steaming and tough creases.

## T-ionicGlide soleplate



T-ionicGlide is our best gliding and scratch-resistant, 5-star rated soleplate with integrated Titanium-Oxide layer.

## Self-Clean



In addition to the built-in calc container, the self-clean function of your soleplate will remove the most stubborn calc. A clean soleplate will improve your steam performance and ironing results.

## Automatic shut-off



The steam iron shuts off automatically when left unattended. It will switch off after 8 minutes when left standing on its heel rest and after 30 seconds when left resting on its soleplate or sides.

## CordGuide



The innovative CordGuide simply clicks onto your ironing board and guides the cord away while you iron.

## Auto Steam Control



Auto Steam Control takes away the worry of selecting the amount of steam you need. Just select the temperature for the garments you're ironing and off you go.

## Triple Precision Tip



The pointed tip on the Philips Azur Performer is very precise in 3 ways: it has a pointed tip, a button groove and a sleek nose design. The Triple Precision tip enables you to reach into even the trickiest areas, e.g. around buttons or between pleats.

Steam iron

Steam 50g/min; 200g steam boost T-ionicGlide soleplate, Safety Auto off + Anti-calc, 2600 Watts

GC4521/87

# Specifications

## Calc management

- Calc clean solution: Self-clean
- Quick Calc Release

## Accessories

- CordGuide

## Easy to use

- Water tank capacity: 300 ml
- Filling and emptying water: Side-opening door
- Safety auto off
- Drip-stop
- Soft grip

- Cord storage: Cord clip
- Power cord length: 2 m

## Fast and powerful crease removal

- Soleplate: T-ionicGlide
- Continuous steam output: 50 g/min
- Power: 2600 W
- Spray
- Steam boost: 200 g
- Vertical steaming
- Ionic deep steam
- Variable steam settings



Issue date 2023-08-22

Version: 1.0.2

EAN: 87 10103 67732 1

© 2023 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)